

OWNER'S MANUAL & OPERATING INSTRUCTIONS



6250 STARTING WATTS / 5500 RUNNING WATTS Recoil Start **PORTABLE GENERATOR**

> ture lear Limited Warrant * Sylear/Ans * Perantie limitée de trois of *



12039 Smith Ave. Santa Fe Springs CA 90670 USA / 1-877-338-0999 www.championpowerequipment.com

SAVE THESE INSTRUCTIONS Important Safety Instructions are included in this manual.


MADE IN CHINA REV 100106-20170111

AN IMPORTANT MESSAGE ABOUT TEMPERATURE:

Your Champion Power Equipment product is designed and rated for continuous operation at ambient temperatures up to 40°C (104°F). When your product is needed your product may be operated at temperatures ranging from -15°C (5°F) to 50°C (122°F) for short periods. If the product is exposed to temperatures outside this range during storage, it should be brought back within this range before operation. In any event, the product must always be operated outdoors, in a well-ventilated area and away from doors, windows and other vents.



Parts Ordering: Mon – Fri 8:30 AM – 5:00 PM (PST/PDT) Toll Free: 1-877-338-0999



JEE

6250 STARTING WATTS / 5500 RUNNING WATTS

Recoil Start PORTABLE GENERATOR

TABLE OF CONTENTS

Introduction	1
Introduction	1
Portable Power Generator	1
Accessories	1
This Booklet	1
Manual Conventions	2
Safety Rules	3
Controls and Features	5
Generator	5
Power Panel	6
Parts Included	7
Wheel Kit.	7
Other	7
Assembly	8
Remove the Generator from the Shipping Carton .	8
Install the Wheel Kit	8
Install the Support Leg	8
Install the Handle	8
Add Engine Oil	9
Add Fuel	10
Grounding	10
Operation	11
Generator Location	11
Grounding	11
Surge Protection	11
Starting the Engine	12
Connecting Electrical Loads	12
Stopping the Engine	12
Do Not Overload Generator	13
Capacity	13
Power Management	13
Operation at High Altitude	13

Maintenance and Storage	14
Engine Maintenance	14
Oil	14
Spark Plugs	14
Air Filter	14
Spark Arrester	15
Cleaning	15
Adjustments	15
Maintenance Schedule	15
Generator Maintenance	16
Storage	16
Generator Storage	16
Disconnect the Battery	16
Charge the Battery	16
Specifications	17
Engine Specifications	17
Generator Specifications	17
Fuel	17
Oil	17
Spark Plugs	17
Valve Clearance	17
Wiring Diagram	18
Parts Diagram	19
Parts List	20
Engine Parts Diagram	21
Engine Parts List	22
Troubleshooting	23

INTRODUCTION

Introduction

Congratulations on your purchase of a Champion Power Equipment product. Champion Power Equipment and Champion Engine Technology designs, builds, and supports all of our products to strict specifications and guidelines. With proper product knowledge, safe use, and regular maintenance, this product should bring years of satisfying service.

Every effort has been made to ensure the accuracy and completeness of the information in this manual, and we reserve the right to change, alter and/or improve the product and this document at any time without prior notice.

Since CPE/CET highly value how our products are designed, manufactured, operated and are serviced, and also highly value your safety and the safety of others, we would like you to take the time to review this product manual and other product materials thoroughly and be fully aware and knowledgeable of the assembly, operation, dangers and maintenance of the product before use. Fully familiarize yourself, and make sure others who plan on operating the product fully familiarize themselves too, with the proper safety and operation procedures before each use. Please always exercise common sense and always error on the side of caution when operating the product to ensure no accidents, property damage, or injury occurs. We want you to continue to use and be satisfied with your CPE/CET product for years to come.

Record the model and serial numbers as well as date and place of purchase for future reference. Have this information available when ordering parts and when making technical or warranty inquiries.

Champion Power Equipment Support
1-877-338-0999
Model Number
100106
Serial Number
Date of Purchase
Purchase Location
For Oil Type see 'Add Engine Oil' section. For Fuel Type see 'Add Fuel' section.

This manual uses the following symbols to help differentiate between different kinds of information. The safety symbol is used with a key word to alert you to potential hazards in operating and owning power equipment. Follow all safety messages to avoid or reduce the risk of serious injury or death.

\land DANGER

DANGER indicates an imminently hazardous situation which, if not avoided, *will* result in death or serious injury.

MWARNING

WARNING indicates a potentially hazardous situation which, if not avoided, *could* result in death or serious injury.

! CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, *may* result in minor or moderate injury.

CAUTION

CAUTION used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, *may* result in property damage.

NOTE

If you have questions regarding your generator, we can help. Please call our help line at **1-877-338-0999**

SAFETY RULES

\land WARNING

Read this manual thoroughly before operating your generator. Failure to follow instructions could result in serious injury or death.

\land DANGER

Generator exhaust contains carbon monoxide, a colorless, odorless, poison gas. Breathing carbon monoxide will cause nausea, dizziness, fainting or death. If you start to feel dizzy or weak, get to fresh air immediately.

Operate generator outdoors only in a well ventilated area.

DO NOT operate the generator inside any building, including garages, basements, crawlspaces and sheds, enclosure or compartment, including the generator compartment of a recreational vehicle. DO NOT allow exhaust fumes to enter a confined area through windows, doors, vents or other openings.

DANGER CARBON MONOXIDE: using a generator indoors CAN KILL YOU IN MINUTES.

\land DANGER

Rotating parts can entangle hands, feet, hair, clothing and/or accessories. Traumatic amputation or severe laceration can result.

Keep hands and feet away from rotating parts. Tie up long hair and remove jewelry. Operate equipment with guards in place. DO NOT wear loose-fitting clothing, dangling drawstrings or items that could become caught.

\land WARNING

Sparks can result in fire or electrical shock.

When servicing the generator:

Disconnect the spark plug wire and place it where it cannot contact the plug. DO NOT check for spark with the plug removed.

Use only approved spark plug testers.

\land DANGER

Generator produces powerful voltage.

DO NOT touch bare wires or receptacles. DO NOT use electrical cords that are worn, damaged

DO NOT use electrical cords that are worn, damaged or frayed.

DO NOT operate generator in wet weather.

DO NOT allow children or unqualified persons to operate or service the generator

Use a ground fault circuit interrupter (GFCI) in damp areas and areas containing conductive material such as metal decking.

Use approved transfer equipment to isolate generator from your electric utility and Notify your utility company before connecting your generator to your power system.

\land WARNING

Running engines produce heat. Severe burns can occur on contact. Combustible material can catch fire on contact.

DO NOT touch hot surfaces. Avoid contact with hot exhaust gases. Allow equipment to cool before touching. Maintain at least 3 ft. (91.4 cm) of clearance on all sides to ensure adequate cooling. Maintain at least 5 ft. (1.5 m) of clearance from combustible materials.

\land WARNING

Medical and Life Support Uses.

In case of emergency, call 911 immediately. NEVER use this product to power life support devices or life support appliances.

NEVER use this product to power medical devices or medical appliances.

Inform your electricity provider immediately if you or anyone in your household depends on electrical equipment to live.

Inform your electrical provider immediately if a loss of power would cause you or anyone in your household to experience a medical emergency.

\land DANGER

Fuel and fuel vapours are highly flammable and extremely explosive.

Fire or explosion can cause severe burns or death. Unintentional startup can result in entanglement, traumatic amputation or laceration.

When adding or removing fuel:

Turn the generator off and let it cool for at least two minutes before removing the fuel cap. Loosen the cap slowly to relieve pressure in the tank.

Only fill or drain fuel outdoors in a well-ventilated area. DO NOT pump gas directly into the generator at the gas station. Use an approved container to transfer the fuel to the generator.

DO NOT overfill the fuel tank.

Always keep fuel away from sparks, open flames, pilot lights, heat and other sources of ignition. DO NOT light or smoke cigarettes.

When starting the generator:

DO NOT attempt to start a damaged generator. Make certain that the gas cap, air filter, spark plug, fuel lines and exhaust system are properly in place. Allow spilled fuel to evaporate fully before attempting to start the engine.

Make certain that the generator is resting firmly on level ground.

When operating the generator:

DO NOT move or tip the generator during operation. DO NOT tip the generator or allow fuel or oil to spill.

When transporting or servicing the generator:

Make certain that the fuel shutoff valve is in the off position and the fuel tank is empty.

Disconnect the spark plug wire.

When storing the generator:

Store away from sparks, open flames, pilot lights, heat and other sources of ignition.

\land WARNING

Operation of this equipment may create sparks that can start fires around dry vegetation.

A spark arrestor may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.

\land WARNING

Rapid retraction of the starter cord will pull hand and arm towards the engine faster than you can let go. Unintentional startup can result in entanglement, traumatic amputation or laceration.

Broken bones, fractures, bruises or sprains could result.

When starting engine, pull the starter cord slowly until resistance is felt and then pull rapidly to avoid kickback.

DO NOT start or stop the engine with electrical devices plugged in.

OCAUTION

Exceeding the generator's running capacity can damage the generator and/or electrical devices connected to it.

DO NOT overload the generator.

Start the generator and allow the engine to stabilize before connecting electrical loads.

Connect electrical equipment in the off position, and then turn them on for operation.

Turn electrical equipment off before stopping the generator.

DO NOT tamper with the governed speed.

DO NOT modify the generator in any way.

! CAUTION

Improper treatment or use of the generator can damage it, shorten its life and void your warranty.

Use the generator only for intended uses. Operate only on level surfaces.

DO NOT expose generator to excessive moisture, dust, or dirt.

DO NOT allow any material to block the cooling slots. If connected devices overheat, turn them off and disconnect them from the generator.


DO NOT use the generator if:

- Electrical output is lost
- Equipment sparks, smokes or emits flames
- Equipment vibrates excessively

CONTROLS AND FEATURES

Read this owner's manual before operating your generator. Familiarize yourself with the location and function of the controls and features. Save this manual for future reference.


Generator



- (1) Fuel Tank 6.1 gallon (23 L) capacity fuel tank.
- (2) Choke Lever Used to start the engine.
- (3) Fuel Valve Turn this valve to the "ON" position to supply fuel to the engine.
- (4) Air Filter Protects the engine by filtering dust and debris from the intake air.
- (5) Recoil Starter Used to start the engine.

- (6) Low Oil Sensor Senses the level of oil in the crankcase and shuts the engine down if the level falls too low.
- (7) Oil Filler Cap Check and fill engine oil level.
- (8) Power Panel See "Power Panel".
- (9) Handle

Power Panel



- (1) **Voltmeter** Displays the output voltage of the generator.
- (2) Circuit Breakers Protects the generator against electrical overload.
- (3) Engine Switch Flip the switch to the "On" position and pull the recoil starter to start the generator. Turn to the "Off" position to turn off the generator.
- (4) 120/240V/30A Twist-Lock Receptacle

 (NEMA L14-30R) May be used to supply
 electrical power for the operation of 120
 and/or 240 Volt AC, 30 Amp, single phase 60 Hz
 electrical loads.
- (5) 120V/20A Duplex (2) (NEMA 5-20R) May be used to supply electrical power for the operation of 120 Volt AC, 20 Amp, single phase 60 Hz electrical loads.
- (6) **Ground Terminal** Consult an electrician for local grounding regulations.


CONTROLS AND FEATURES

Parts Included

Your 100106 gasoline powered generator ships with the following parts:

Wheel Kit

_	8 in. Wheel
_	Bushing
_	Flange Bolt (M10x105 for Wheel)
_	Flat Washer Ø10
_	Lock Nut (M10)
_	Support Leg w/Vibration Mounts
_	Flange Bolt (M8x16 for Support Leg) 2
_	Handle
_	Flange Bolt (M8x45 for Handle) 2
_	Flange Lock Nut (M8) 4
Otl	her
_	Oil Funnel
_	Spark Plug Socket



Your generator requires some assembly. This unit ships from our factory without oil. It must be properly serviced with fuel and oil before operation.

If you have any questions regarding the assembly of your generator, call our help line at 1-877-338-0999. Please have your serial number and model number available.

Remove the Generator from the Shipping Carton

- 1. Set the shipping carton on a solid, flat surface.
- 2. Remove everything from the carton except the generator.
- Carefully cut each corner of the box from top to bottom. Fold each side flat on the ground to provide a surface area to install the wheel kit and support leg.


Install the Wheel Kit

() CAUTION

The wheel kit is not intended for over-the-road use.


You will need the following tools to install the wheels:

- 17 mm wrench OR adjustable wrench (not included)
- Socket wrench with a 16 mm socket (not included)
- Pliers (not included)
- 1. Before adding fuel and oil, tip the generator on it's side.
- 2. Slide the flange bolt (M10x105) through the washer, sleeve and wheel.
- 3. Slide the bolt through the mount point on the frame.
- 4. Fasten securely with the M10 lock nut.
- 5. Repeat steps 2-4 to attach the second wheel.




Install the Support Leg

- 1. Attach the support leg to the generator frame with flange bolts (M8x16) and flange lock nuts (M8).
- 2. Tip the generator slowly so that it rests on the wheels and support leg.



Install the Handle

- 1. Place the handle over the mounting channel on the frame.
- 2. Secure the handle to the frame using the two handle flange bolts (M8x45).
- Place a flange lock nut (M8) on the end of each bolt and fasten securely. DO NOT over tighten the flange lock nuts.



ASSEMBLY

Add Engine Oil

! CAUTION

DO NOT attempt to crank or start the engine before it has been properly filled with the recommended type and amount of oil. Damage to the generator as a result of failure to follow these instructions will void your warranty.


NOTE

The generator rotor has a sealed, pre-lubricated ball bearing that requires no additional lubrication for the life of the bearing.

NOTE

The recommended oil type is 10W-30 automotive oil.


1. Place the generator on a flat, level surface.



- 2. Remove oil fill cap/dipstick to add oil.
- 3. Add up to 1.2 qt. (1.1 L) of oil (not included) and replace oil fill cap/dipstick. DO NOT OVERFILL.
- 4. Check engine oil level daily and add as needed.

NOTE

Once oil has been added, a visual check should show oil about 1-2 threads from running out of the fill hole. If using the dipstick to check oil level, DO NOT screw in the dipstick while checking.



Add Engine Oil Cont'd.

NOTE


Check oil often during the break-in period. Refer to the Maintenance section for recommended service intervals.

CAUTION

The engine is equipped with a low oil shut-off and will stop when the oil level in the crankcase falls below the threshold level.

NOTE

We consider the first 5 hours of run time to be the break-in period for the unit. During the break in period stay at or below 50% of the running watt rating and vary the load occasionally to allow stator windings to heat and cool. Adjusting the load will also cause engine speed to vary and help seat piston rings. After the 5 hour break-in period, change the oil.



NOTE


Weather will affect engine oil and engine performance. Change the type of engine oil used based on weather conditions to suit the engine needs.

NOTE

Synthetic oil may be used after the 5 hour initial break-in period. Using synthetic oil does not increase the recommended oil change interval.

Add Fuel

- Use clean, fresh, regular unleaded fuel with a minimum octane rating of 85 and an ethanol content of less than 10% by volume.
- 2. DO NOT mix oil with fuel.
- 3. Clean the area around the fuel cap.
- 4. Remove the fuel cap.
- 5. Slowly add fuel to the tank. DO NOT OVERFILL. Fuel can expand after filling. A minimum of 6.4 mm (¼ in.) of space left in the tank is required for fuel expansion, more than 6.4 mm (¼ in.) is recommended. Fuel can be forced out of the tank as a result of expansion if it is overfilled, and can affect the stable running condition of the product. When filling the tank, it is recommended to leave enough space for the fuel to expand.



6. Screw on the fuel cap and wipe away any spilled fuel.

! CAUTION

Use regular unleaded gasoline with a minimum octane rating of 85.

Do not mix oil and gasoline.

Fill tank to approximately 6.4 mm ($\frac{1}{4}$ in.) below the top of the tank to allow for fuel expansion.

DO NOT pump gas directly into the generator at the gas station. Use an approved container to transfer the fuel to the generator.

DO NOT fill fuel tank indoors.

DO NOT fill fuel tank when the engine is running or hot. DO NOT overfill the fuel tank.

DO NOT light cigarettes or smoke when filling the fuel tank.

A WARNING

Pouring fuel too fast through the fuel screen may result in blow back of fuel at the operator while filling.

Add Fuel Cont'd.

NOTE

Our engines work well with 10% or less ethanol blend fuels. When using blended fuels there are some issues worth noting:

- Ethanol-gasoline blends can absorb more water than gasoline alone.
- These blends can eventually separate, leaving water or a watery goo in the tank, fuel valve and carburetor.
- With gravity-fed fuel supplies, this compromised fuel can be drawn into the carburetor and cause damage to the engine and/or potential hazards.
- There are only a few suppliers of fuel stabilizer that are formulated to work with ethanol blend fuels.
- Any damages or hazards caused by using improper fuel, improperly stored fuel, and/ or improperly formulated stabilizers, are not covered by manufacture's warranty.

It is advisable to always shut off the fuel supply, run the engine to fuel starvation and drain the tank when the equipment is not in use for more than 30 days.

Grounding

Your generator must be properly connected to an appropriate ground to help prevent electric shock.

MWARNING

Failure to properly ground the generator can result in electric shock.

A ground terminal connected to the frame of the generator has been provided on the power panel. For remote grounding, connect of a length of heavy gauge (12 AWG minimum) copper wire between the generator ground terminal and a copper rod driven into the ground. We strongly recommend that you consult with a qualified electrician to ensure compliance with local electrical codes.

OPERATION

Generator Location

NEVER operate the generator inside any building, including garages, basements, crawlspaces and sheds, enclosure or compartment, including the generator compartment of a recreational vehicle. Please consult your local authority. In some areas, generators must be registered with the local utility. Generators used at construction sites may be subject to additional rules and regulations. Generators should be on a flat, level surface at all times. (Even while not in operation) Generators must have at least 5 ft. (1.5 m) of clearance from all combustible material. In addition to clearance from all combustible material, generators must also have at least 3 ft. (91.4 cm) of clearance on all sides to allow for adequate cooling, maintenance and servicing. Generators should never be started or operated in the back of a SUV, camper, trailer, in the bed of a truck (regular, flat or otherwise), under staircases/stairwells, next to walls or buildings, or in any other location that will not allow for adequate cooling of the generator and/or the muffler. DO NOT contain generators during operation. Allow generators to properly cool before transport or storage. Place the generator in a well-ventilated area. DO NOT place the generator near vents or intakes where exhaust fumes could be drawn into occupied or confined spaces. Carefully consider wind and air currents when positioning generator.

Failure to follow proper safety precautions may void manufacturer's warranty.

\land WARNING

Do not operate or store the generator in rain, snow, or wet weather.

Using a generator or electrical appliance in wet conditions, such as rain or snow, or near a pool or sprinkler system, or when your hands are wet, could result in electrocution.

A WARNING

During operation the muffler and exhaust fumes produced will become hot. If adequate cooling and breathing space are not supplied, or if the generator is blocked or contained, temperatures can become extremely heated and may lead to fire.

Grounding

The generator system ground connects the frame to the ground terminals on the power panel. The system ground is connected to the AC neutral wire.

Surge Protection

CAUTION

Voltage fluctuation may impair the proper functioning of sensitive electronic equipment.

Electronic devices, including computers and many programmable appliances use components that are designed to operate within a narrow voltage range and may be affected by momentary voltage fluctuations. While there is no way to prevent voltage fluctuations, you can take steps to protect sensitive electronic equipment.

 Install UL1449, CSA-listed, plug-in surge suppressors on the outlets feeding your sensitive equipment. Surge suppressors come in single- or multi-outlet styles. They're designed to protect against virtually all short-duration voltage fluctuations.

Starting the Engine

- 1. Make certain the generator is on a flat, level surface.
- Disconnect all electrical loads from the generator. Never start or stop the generator with electrical devices plugged in or turned on.
- 3. Turn the fuel valve to the "ON" position.
- 4. Flip the engine switch to the "ON" position.
- 5. Move the choke lever to the "CHOKE" position.
- 6. Pull the starter cord slowly until resistance is felt and then pull rapidly
- 7. Do not over-choke. As soon as engine starts, move the choke lever to the "RUN" position.

NOTE

Keep choke lever in "Choke" position for only 1 pull of the recoil starter. After first pull, move choke lever to the "Run" position for up to the next 3 pulls of the recoil starter. Too much choke leads to sparkplug fouling/engine flooding due to the lack of incoming air. This will cause the engine not to start.

NOTE

If the engine starts but does not run make certain that the generator is on a flat, level surface. The engine is equipped with a low oil sensor that will prevent the engine from running when the oil level falls below a critical threshold.

Connecting Electrical Loads

- 1. Let the engine stabilize and warm up for a few minutes after starting
- 2. Plug in and turn on the desired 120/240 Volt AC single phase, 60 Hz electrical loads.
- DO NOT connect 3-phase loads to the generator.
- DO NOT connect 50 Hz loads to the generator.
- DO NOT overload the generator.

NOTE

Connecting a generator to your electric utility company's power lines or to another power source may be against the law. In addition this action, if done incorrectly, could damage your generator and appliances and could cause serious injury or even death to you or a utility worker who may be working on nearby power lines. If you plan to run a portable electric generator during an outage, please notify your electric utility company immediately and remember to plug your appliances directly into the generator. Do not plug the generator into any electric outlet in your home. Doing so could create a connection to the utility company power lines. You are responsible for ensuring that your generator's electricity does not feed back into the electric utility power lines.

If the generator will be connected to a building electrical system, consult your local utility company or a qualified electrician. Connections must isolate generator power from utility power and must comply with all applicable laws and codes.

Stopping the Engine

- 1. Turn off and unplug all electrical loads. Never start or stop the generator with electrical devices plugged in or turned on.
- 2. Let the generator run at no-load for several minutes to stabilize internal temperatures of the engine and generator.
- 3. Turn the fuel valve to the "OFF" position.
- 4. Let the engine run until fuel starvation has stopped the engine. This usually takes a few minutes.
- 5. Press the engine switch to the "OFF" position.

Important: Always ensure that the Fuel Valve and the Engine Switch are in the "OFF" position when the engine is not in use.

NOTE

If the engine will not be used for a period of two (2) weeks or longer, please see the Storage section for proper engine and fuel storage.

Do Not Overload Generator

Capacity

Follow these simple steps to calculate the running and starting watts necessary for your purposes.

- 1. Select the electrical devices you plan on running at the same time.
- 2. Total the running watts of these items. This is the amount of power you need to keep your items running.
- 3. Identify the highest starting wattage of all devices identified in step 1. Add this number to the number calculated in step 2. Surge wattage is the extra burst of power needed to start some electric driven equipment. Following the steps listed under "Power Management" will guarantee that only one device will be starting at a time.

Power Management

Use the following formula to convert voltage and amperage to watts:

Volts x Amps = Watts

To prolong the life of your generator and attached devices, follow these steps to add electrical load:

- 1. Start the generator with no electrical load attached
- 2. Allow the engine to run for several minutes to stabilize.
- 3. Plug in and turn on the first item. It is best to attach the item with the largest load first.
- 4. Allow the engine to stabilize.
- 5. Plug in and turn on the next item.
- 6. Allow the engine to stabilize.
- 7. Repeat steps 5-6 for each additional item.

NOTE

Never exceed the specified capacity when adding loads to the generator.

Operation at High Altitude

The density of air at high altitude is lower than at sea level. Engine power is reduced as the air mass and airfuel ratio decrease. Engine power and generator output will be reduced approximately 3½% for every 304.8 m (1,000 ft.) of elevation above sea level. This is a natural trend and cannot be changed by adjusting the engine. At high altitudes increased exhaust emissions can also result due to the increased enrichment of the air- fuel ratio. Other high-altitude issues can include hard starting, increased fuel consumption and spark plug fouling.

To alleviate high-altitude issues other than the natural power loss, Champion Power Equipment can provide a high-altitude carburetor main jet. The alternative main jet and installation instructions can be obtained by contacting Customer Support. Installation instructions are also available in the Technical Bulletin area of the Champion Power Equipment internet site.

The part number and recommended minimum altitude for the application of the high-altitude carburetor main jet is listed in the table below.

In order to select the correct high-altitude main jet it is necessary to identify the carburetor model. For this purpose, a code is stamped on the side of the carburetor. Select the correct main jet part number corresponding to the carburetor code found on your particular carburetor.

Carburetor Code	Main Jet	Part Number	Altitude
P23-2-H	Standard	46.131017.21.H	
P23-2-H	Altitude	46.131017.21.01.H	
P23-2-Z	Standard	46.131017.21.Z	1,372 Metres
FZ3-Z-Z	Altitude	46.131017.21.01.Z	(4,500 Feet)
P23-2-Y	Standard	46.131017.21.Y	
P23-2-1	Altitude	46.131017.21.01.Y	

MARNING

Operation using the alternative main jet at elevations lower than the recommended minimum altitude can damage the engine. For operation at lower elevations, the standard main jet must be used. Operating the engine with the wrong engine configuration at a given altitude may increase its emissions and decrease fuel efficiency and performance. The owner/operator is responsible for all periodic maintenance.

WARNING

Never operate a damaged or defective generator.

MWARNING

Tampering with the factory set governor will void your warranty.

MWARNING

Improper maintenance will void your warranty.

NOTE

Maintenance, replacement, or repair of emission control devices and systems may be performed by any non-road engine repair establishment or individual.

Complete all scheduled maintenance in a timely manner. Correct any issue before operating the generator.

NOTE

For service or parts assistance, contact our help line at **1-877-338-0999**

Engine Maintenance

To prevent accidental starting, remove and ground spark plug wire before performing any service.

0il


Change oil when the engine is warm. Refer to the oil specification to select the proper grade of oil for your operating environment.

- 1. Remove the oil drain plug with a 15 mm (0.6 in.) socket and extension (not included).
- 2. Allow the oil to drain completely.
- 3. Replace the drain plug.
- 4. Remove oil fill cap/dipstick to add oil.
- 5. Add up to 1.2 qt (1.1 L) of oil and replace oil fill cap/dipstick. DO NOT OVERFILL.
- 6. Dispose of used oil at an approved waste management facility.

Oil Cont'd.


NOTE

Once oil has been added, a visual check should show oil about 1-2 threads from running out of the fill hole. If using the dipstick to check oil level, DO NOT screw in the dipstick while checking.



Spark Plugs

- 1. Remove the spark plug cable from the spark plug.
- 2. Use the spark plug tool that shipped with your generator to remove the plug.
- 3. Inspect the electrode on the plug. It must be clean and not worn to produce the spark required for ignition.
- Make certain the spark plug gap is 0.7 0.8 mm or (0.028 - 0.031 in.).




- Refer to the spark plug recommendation in Specifications section when replacing the plug.
- 6. Carefully thread the plug into the engine.
- 7. Use the spark plug tool to firmly install the plug.
- 8. Attach the spark plug wire to the plug.

Air Filter

- 1. Remove the snap-on cover holding the air filter to the assembly.
- 2. Remove the foam element.
- 3. Wash in liquid detergent and water. Squeeze thoroughly dry in a clean cloth.
- 4. Saturate in clean engine oil.
- 5. Squeeze in a clean, absorbent cloth to remove all excess oil.
- 6. Place the filter in the assembly.
- 7. Reattach the air filter cover and snap in place.

Spark Arrester

- 1. Allow the engine to cool completely before servicing the spark arrester.
- 2. Remove the screws (3) holding the cover plate which retains the end of the spark arrester to the muffler.
- 3. Remove the spark arrester screen.
- 4. Carefully remove the carbon deposits from the spark arrester screen with a wire brush.
- 5. Replace the spark arrester if it is damaged.
- 6. Position the spark arrester in the muffler and attach with the screws (3).



() CAUTION

Failure to clean the spark arrester will result in degraded engine performance.

Cleaning

! CAUTION

DO NOT spray engine with water.

Water can contaminate the fuel system.

Use a damp cloth to clean exterior surfaces of the engine. Use a soft bristle brush to remove dirt and oil.

Use an air compressor (25 PSI) to clear dirt and debris from the engine.

Adjustments

The air-fuel mixture is not adjustable. Tampering with the governor can damage your generator and your electrical devices and will void your warranty. CPE recommends that you contact our service line at **1-877-338-0999** for all other service and/or adjustment needs.

Maintenance Schedule

Follow the service intervals indicated in the following maintenance schedule.

Service your generator more frequently when operating in adverse conditions.

Contact our help line at **1-877-338-0999** to locate the nearest Champion Power Equipment certified service dealer for your generator or engine maintenance needs.

Every 8 hours or daily		
Check oil level		
Clean around air intake and muffler		
First 5 hours		
Change oil		
Every 50 hours or every season		
Clean air filter		
Change oil if operating under heavy load or in hot environments		
Every 100 hours or every season		
Change oil		
Clean/Adjust spark plug		
Check/Adjust valve clearance*		
Clean spark arrester		
Clean fuel tank and filter*		
Every 250 hours		
Clean combustion chamber*		
Every 3 years		
Replace fuel line		

*To be performed by knowledgeable, experienced owners or Champion Power Equipment certified dealers.

Generator Maintenance

Make certain that the generator is kept clean and stored properly. Only operate the unit on a flat, level surface in a clean, dry operating environment. DO NOT expose the unit to extreme conditions, excessive dust, dirt, moisture or corrosive vapors.

! CAUTION

DO NOT use a garden hose to clean the generator.

Water can enter the generator through the cooling slots and damage the generator windings.

Use a damp cloth to clean exterior surfaces of the generator. Use a soft bristle brush to remove dirt and oil.

Use an air compressor (25 PSI) to clear dirt and debris from the generator.

Inspect all air vents and cooling slots to ensure that they are clean and unobstructed.

Storage

The generator should be started at least once every 14 days and allowed to run for at least 20 minutes. For longer term storage, please follow these guidelines.

Generator Storage

- 1. Add a properly formulated fuel stabilizer to the tank.
- 2. Be sure all appliances are disconnected from the generator.
- 3. Run the generator for a few minutes so the treated fuel cycles through the fuel system and carburetor.
- 4. Turn the fuel valve to the "Off" position.
- 5. Let the generator run until fuel starvation has stopped the engine. This usually takes a few minutes.
- 6. The generator needs to cool completely before cleaning and storage.
- 7. Clean the generator according to the maintenance section.
- 8. Change the oil.
- Remove the spark plug and pour about 1/2 ounce (14.8 mL) of oil into the cylinder. Crank the engine slowly to distribute the oil and lubricate the cylinder.
- 10. Reattach the spark plug.
- 11. Store the unit in a clean, dry place out of direct sunlight.

Generator Storage Cont'd.

NOTE

Our engines work well with 10% or less ethanol blend fuels. When using blended fuels there are some issues worth noting:

- Ethanol-gasoline blends can absorb more water than gasoline alone.
- These blends can eventually separate, leaving water or a watery goo in the tank, fuel valve and carburetor.
- With gravity-fed fuel supplies, this compromised fuel can be drawn into the carburetor and cause damage to the engine and/or potential hazards.
- There are only a few suppliers of fuel stabilizer that are formulated to work with ethanol blend fuels.
- Any damages or hazards caused by using improper fuel, improperly stored fuel, and/ or improperly formulated stabilizers, are not covered by manufacture's warranty.

It is advisable to always shut off the fuel supply, run the engine to fuel starvation and drain the tank when the equipment is not in use for more than 30 days.

\land DANGER

Generator exhaust contains odorless and colorless carbon monoxide gas.

To avoid accidental or unintended ignition of your generator during periods of storage, the following precautions should be followed:

 When storing the generator for short or extended periods of time make sure that the Engine Switch and the Fuel Valve are set in the OFF position.

SPECIFICATIONS

Engine Specifications

-	Model
_	Displacement
_	Type
_	Start Type Recoil

Generator Specifications

_	Model
_	Running Wattage
_	Starting Wattage
_	AC Voltage
_	Phase Single
_	Frequency
_	Fuel Capacity
_	Gross Weight
_	Net Weight
_	Height
_	Width
_	Length


Fuel

Fuel capacity is 6.1 gallons (23 L). Use regular unleaded gasoline with a minimum octane rating of 85 and an ethanol content of less than 10% by volume.

0il

Use 10W-30 automotive oil. Oil capacity is up to 1.2 qt (1.1 L). DO NOT OVERFILL. Please reference the following chart for recommended

oil types for use in the generator.



NOTE

Weather will affect engine oil and engine performance. Change the type of engine oil used based on weather conditions to suit the engine needs.

Spark Plugs

OEM spark plug: NHSP F6RTC

Replacement spark plug: NGK BPR6ES or equivalent Make certain the spark plug gap is 0.7 - 0.8 mm or (0.028 - 0.031 in.).


Maintenance Valve Clearance

Intake: 0.13 – 0.17 mm (0.005 – 0.007 in.)
Exhaust: 0.18 – 0.22 mm (0.007 – 0.009 in.)
Note: Tech bulletin regarding the valve adjustment procedure is on www.championpowerequipment.com.

An Important Message About Temperature

Your Champion Power Equipment product is designed and rated for continuous operation at ambient temperatures up to 40°C (104°F). When your product is needed your product may be operated at temperatures ranging from -15°C (5°F) to 50°C (122°F) for short periods. If the product is exposed to temperatures outside this range during storage, it should be brought back within this range before operation. In any event, the product must always be operated outdoors, in a well-ventilated area and away from doors, windows and other vents.

Wiring Diagram




æ

ප|ප

SPECIFICATIONS

Parts Diagram




#	Part Number	Description	Qty
1	2.06.006	Clamp (Ø7ר1)	1
2	24.070030.00	Hole, Breather Tube	1
3	2.05.001	Clamp (Ø8×6.5)	2
4	152.070014.06	Pipe, Reversal Valve (730 mm)	1
5	122.070100.07	Fuel Tank Cap	1
6	122.070300.03	Fuel Filter	1
7	24.070800.00	Reversal Valve	1
8	152.071000.31.48	Fuel Tank, Yellow	1
9	1.5789.0620	Flange Bolt M6×20	4
10	1.93.06	Lock Washer Ø6	8
11	2.03.004	Washer Ø6	4
12	122.070015.01	Mount Vibration, Fuel Tank	4
13	122.070400.05	Fuel Cock	1
14	2.06.016	Clamp (Ø8.7×b6)	2
15	152.070011.07	Pipe, Fuel (7.7")	1
16	45.090006.20	Holder, Air Cleaner	1
17	1.6177.1.06	Flange Lock Nut M6	2
18	1.848.08	Washer Ø8	2
19	1.93.08	Lock Washer Ø8	4
20	1.6175.08	Nut M8	2
21	46.100001.07	Gasket, Muffler	1
22	46.101000.13.2	Muffler Assembly	1
23	1.9074.4.0510	Screw/Washer Assembly M5×10	3
24	46.101300.00	Spark Arrester Assembly	1
25	2.13.009	Bush (Ø9ר13×16)	1
26	1.16674.0820	Flange Bolt M8×20	1
27	1.16674.0835	Flange Bolt M8×35	1
28	1.6175.05	Nut M5	2
29	1.97.1.05	Washer Ø5	4
30	1.93.05	Lock Washer Ø5	5
31	2.08.100	Bolt M5×204	2
32	1.97.1.06	Washer Ø6	4
33	152.190300.00	Carbon Brush Assembly	1
34	122.190004.01	Pinch, Carbon Brush	1
35	1.5783.0520	Bolt M5×20	1
36	1.16674.0512.2	Flange Bolt M5×12	2
37	152.190003.00.48	Generator End Cover, Yellow	1
38	1.5783.0516	Bolt M5×16	2
39	122.190400.00	Terminal Block	1
40	1.16674.0516	Flange Bolt M5×16	3
41	153.190200.04	AVR	1
42	152.190002.00	End Housing	1
43	2.08.065	Flange Bolt M6×168	4
44	152.191002.03	Stator Cover	1
45	2.08.101	Flange Bolt M10×255	1
46	152.191200.28	Stator Assembly, AI, 130 mm, NO DC	1
47	1.7244.10	Lock Washer Ø10	1
48	1.96.10	Washer Ø10	3
49	152.191100.28	Rotor Assembly, AI, 130 mm	1

# Part Number Description 50 1.5789.0608 Flange Bolt M6x8 51 152.192300.01 Air Guide 52 152.190005.00 Rubber, Fore-Cover, A 53 152.190005.01 Rubber, Fore-Cover, B 54 44.403 Engine 55 152.200700.12.2 Handle 56 1.6177.1.08 Nut M8 57 1.5789.0845 Flange Bolt M8x45 58 6.5.237.392.2 Frame 59 1.6177.1.10 Nut M10 60 152.201200.03 Motor Mount I 61 1.6182.10 Nut M10 62 1.5782.10105 Bolt M10×105 63 122.200016.01 Bushing (Ø16ר10.5×59) 64 122.201701.05.48 Sin. Wheel 65 152.20120.04 Motor Mount II 66 1.5789.0825 Flange Bolt M8×25 67 152.200002.00.2 Support Leg 60 mm 68 152.201400.00 Rubber, Support 69 1.5789.061	Qty 1 1 1 1 1 1 1 1 2 1
1 1 1 51 152.192300.01 Air Guide 52 152.190005.00 Rubber, Fore-Cover, A 53 152.190005.01 Rubber, Fore-Cover, B 54 44.403 Engine 55 152.200700.12.2 Handle 56 1.6177.1.08 Nut M8 57 1.5789.0845 Flange Bolt M8x45 58 6.5.237.392.2 Frame 59 1.6177.1.10 Nut M10 60 152.201200.03 Motor Mount I 61 1.6182.10 Nut M10 62 1.5782.10105 Bolt M10×105 63 122.201701.05.48 8in. Wheel 64 122.201701.05.48 8in. Wheel 65 152.201200.04 Motor Mount II 66 1.5789.0825 Flange Bolt M8x25 67 152.201400.00 Rubber, Support 68 152.201400.00 Rubber, Support 69 1.5789.0816 Flange Bolt M8x16 70 1.862.06 Lock Washer Ø6<	1 1 1 1 1 1 10 2
52 152.190005.00 Rubber, Fore-Cover, A 53 152.190005.01 Rubber, Fore-Cover, B 54 44.403 Engine 55 152.200700.12.2 Handle 56 1.6177.1.08 Nut M8 57 1.5789.0845 Flange Bolt M8x45 58 6.5.237.392.2 Frame 59 1.6177.1.10 Nut M10 60 152.201200.03 Motor Mount I 61 1.6182.10 Nut M10 62 1.5782.10105 Bolt M10×105 63 122.20016.01 Bushing (Ø16ר10.5×59) 64 122.201701.05.48 8in. Wheel 65 152.201200.04 Motor Mount II 66 1.5789.0825 Flange Bolt M8×25 67 152.201400.00 Rubber, Support 68 152.201400.00 Rubber, Support 69 1.5789.0816 Flange Bolt M8×16 70 1.862.06 Lock Washer Ø6 71 1.5789.0612 Flange Bolt M6×12 72 5.1900	1 1 1 1 1 10 2
53 152.190005.01 Rubber, Fore-Cover, B 54 44.403 Engine 55 152.200700.12.2 Handle 56 1.6177.1.08 Nut M8 57 1.5789.0845 Flange Bolt M8x45 58 6.5.237.392.2 Frame 59 1.6177.1.10 Nut M10 60 152.201200.03 Motor Mount I 61 1.6182.10 Nut M10 62 1.5782.10105 Bolt M10×105 63 122.200016.01 Bushing (Ø16ר10.5×59) 64 122.201701.05.48 8in. Wheel 65 152.201200.04 Motor Mount II 66 1.5789.0825 Flange Bolt M8×25 67 152.201400.00 Rubber, Support 68 152.201400.00 Rubber, Support 69 1.5789.0816 Flange Bolt M8×16 70 1.862.06 Lock Washer Ø6 71 1.5789.0612 Flange Bolt M6×12 72 5.1900.029 Grounding Line 73 100106.21	1 1 1 10 2
54 44.403 Engine 55 152.200700.12.2 Handle 56 1.6177.1.08 Nut M8 57 1.5789.0845 Flange Bolt M8x45 58 6.5.237.392.2 Frame 59 1.6177.1.10 Nut M10 60 152.201200.03 Motor Mount I 61 1.6182.10 Nut M10 62 1.5782.10105 Bolt M10x105 63 122.200016.01 Bushing (Ø16xØ10.5x59) 64 122.201701.05.48 8in. Wheel 65 152.201200.04 Motor Mount II 66 1.5789.0825 Flange Bolt M8x25 67 152.201000.02.00.2 Support Leg 60 mm 68 152.201400.00 Rubber, Support 69 1.5789.0816 Flange Bolt M8x16 70 1.862.06 Lock Washer Ø6 71 1.5789.0612 Flange Bolt M6x12 72 5.1900.029 Grounding Line 73 100106.21 Control Panel Assembly 74 5.180.000 Rectifier 77 1.9074.1.0538.2 Screw/W	1 1 10 2
55 152.200700.12.2 Handle 56 1.6177.1.08 Nut M8 57 1.5789.0845 Flange Bolt M8×45 58 6.5.237.392.2 Frame 59 1.6177.1.10 Nut M10 60 152.201200.03 Motor Mount I 61 1.6182.10 Nut M10 62 1.5782.10105 Bolt M10×105 63 122.200016.01 Bushing (Ø16ר10.5×59) 64 122.201701.05.48 8in. Wheel 65 152.201200.04 Motor Mount II 66 1.5789.0825 Flange Bolt M8×25 67 152.201002.00.2 Support Leg 60 mm 68 152.201400.00 Rubber, Support 69 1.5789.0816 Flange Bolt M8×16 70 1.862.06 Lock Washer Ø6 71 1.5789.0612 Grounding Line 72 5.1900.029 Grounding Line 73 100106.21 Control Panel Assembly 74 5.1810.000 Rectifier 75 1.823.0514 Screw/Washer Assembly M52 78 1.2003.00	10 2
57 1.5789.0845 Flange Bolt M8×45 58 6.5.237.392.2 Frame 59 1.6177.1.10 Nut M10 60 152.201200.03 Motor Mount I 61 1.6182.10 Nut M10 62 1.5782.10105 Bolt M10×105 63 122.200016.01 Bushing (Ø16ר10.5×59) 64 122.201701.05.48 8in. Wheel 65 152.201200.04 Motor Mount II 66 1.5789.0825 Flange Bolt M8×25 67 152.201400.00 Rubber, Support 68 152.201400.00 Rubber, Support 69 1.5789.0816 Flange Bolt M8×16 70 1.862.06 Lock Washer Ø6 71 1.5789.0612 Flange Bolt M6×12 72 5.1900.029 Grounding Line 73 100106.21 Control Panel Assembly 74 5.1800.000 Rectifier 77 1.9074.1.0538.2 Screw/Washer Assembly M5x 78 122.210003.00 Grommet 79 152.15.35.2 Control Panel 80 5.1400.003	2
58 6.5.237.392.2 Frame 59 1.6177.1.10 Nut M10 60 152.201200.03 Motor Mount I 61 1.6182.10 Nut M10 62 1.5782.10105 Bolt M10×105 63 122.200016.01 Bushing (Ø16ר10.5×59) 64 122.201701.05.48 8in. Wheel 65 152.201200.04 Motor Mount II 66 1.5789.0825 Flange Bolt M8×25 67 152.201400.00 Rubber, Support 68 152.201400.00 Rubber, Support 69 1.5789.0816 Flange Bolt M8×16 70 1.862.06 Lock Washer Ø6 71 1.5789.0612 Flange Bolt M6×12 72 5.1900.029 Grounding Line 73 100106.21 Control Panel Assembly 74 5.1800.000 Rectifier 77 1.9074.1.0538.2 Screw/Washer Assembly M53 78 122.210003.00 Grommet 79 152.15.35.2 Control Panel 80	
59 1.6177.1.10 Nut M10 60 152.201200.03 Motor Mount I 61 1.6182.10 Nut M10 62 1.5782.10105 Bolt M10×105 63 122.200016.01 Bushing (Ø16ר10.5×59) 64 122.201701.05.48 8in. Wheel 65 152.201200.04 Motor Mount II 66 1.5789.0825 Flange Bolt M8×25 67 152.20002.00.2 Support Leg 60 mm 68 152.201400.00 Rubber, Support 69 1.5789.0816 Flange Bolt M8×16 70 1.862.06 Lock Washer Ø6 71 1.5789.0612 Flange Bolt M6×12 72 5.1900.029 Grounding Line 73 100106.21 Control Panel Assembly 74 5.1810.000 Neet Withit 75 1.823.0514 Screw/M5×14 76 5.1800.000 Rectifier 77 1.9074.1.0538.2 Screw/Washer Assembly M5x 78 122.21003.00 Grommet 79	
60 152.201200.03 Motor Mount I 61 1.6182.10 Nut M10 62 1.5782.10105 Bolt M10×105 63 122.200016.01 Bushing (Ø16ר10.5×59) 64 122.201701.05.48 8in. Wheel 65 152.201200.04 Motor Mount II 66 1.5789.0825 Flange Bolt M8×25 67 152.200002.00.2 Support Leg 60 mm 68 152.201400.00 Rubber, Support 69 1.5789.0816 Flange Bolt M8×16 70 1.862.06 Lock Washer Ø6 71 1.5789.0612 Flange Bolt M6×12 72 5.1900.029 Grounding Line 73 100106.21 Control Panel Assembly 74 5.1800.000 Rectifier 77 1.9074.1.0538.2 Screw/Washer Assembly M5x 78 122.210003.00 Grommet 79 152.15.35.2 Control Panel 80 5.1400.003 Voltage Meter 80 5.1400.004 Ignition Switch	1
61 1.6182.10 Nut M10 62 1.5782.10105 Bolt M10×105 63 122.200016.01 Bushing (Ø16ר10.5×59) 64 122.201701.05.48 8in. Wheel 65 152.201200.04 Motor Mount II 66 1.5789.0825 Flange Bolt M8×25 67 152.201400.00 Rubber, Support Leg 60 mm 68 152.201400.00 Rubber, Support 69 1.5789.0816 Flange Bolt M8×16 70 1.862.06 Lock Washer Ø6 71 1.5789.0612 Flange Bolt M6×12 72 5.1900.029 Grounding Line 73 100106.21 Control Panel Assembly 74 5.1810.000 Over Voltage Protector 75 1.823.0514 Screw M5×14 76 5.1800.000 Rectifier 77 1.9074.1.0538.2 Screw/Washer Assembly M5x 78 122.210003.00 Grommet 79 152.15.35.2 Control Panel 80 5.1400.003 Voltage Meter 81 5.1000.004 Ignition Switch	4
62 1.5782.10105 Bolt M10×105 63 122.20016.01 Bushing (Ø16ר10.5×59) 64 122.201701.05.48 8in. Wheel 65 152.201200.04 Motor Mount II 66 1.5789.0825 Flange Bolt M8×25 67 152.200002.00.2 Support Leg 60 mm 68 152.201400.00 Rubber, Support 69 1.5789.0816 Flange Bolt M8×16 70 1.862.06 Lock Washer Ø6 71 1.5789.0612 Flange Bolt M6×12 72 5.1900.029 Grounding Line 73 100106.21 Control Panel Assembly 74 5.1810.000 Rectifier 75 1.823.0514 Screw/Msher Assembly M52 76 5.1800.000 Rectifier 77 1.9074.1.0538.2 Screw/Washer Assembly M52 78 122.210003.00 Grommet 79 152.15.35.2 Control Panel 80 5.1400.003 Voltage Meter 81 5.1000.004 Ignition Switch	2
63 122.200016.01 Bushing (Ø16ר10.5×59) 64 122.201701.05.48 8in. Wheel 65 152.201200.04 Motor Mount II 66 1.5789.0825 Flange Bolt M8×25 67 152.200002.00.2 Support Leg 60 mm 68 152.201400.00 Rubber, Support 69 1.5789.0816 Flange Bolt M8×16 70 1.862.06 Lock Washer Ø6 71 1.5789.0612 Flange Bolt M6×12 72 5.1900.029 Grounding Line 73 100106.21 Control Panel Assembly 74 5.1810.000 Over Voltage Protector 75 1.823.0514 Screw M5×14 76 5.1800.000 Rectifier 77 1.9074.1.0538.2 Screw/Washer Assembly M5x 78 122.210003.00 Grommet 79 152.15.35.2 Control Panel 80 5.1400.003 Voltage Meter 81 5.1000.004 Ignition Switch	2
64 122.201701.05.48 8in. Wheel 65 152.201200.04 Motor Mount II 66 1.5789.0825 Flange Bolt M8×25 67 152.200002.00.2 Support Leg 60 mm 68 152.201400.00 Rubber, Support 69 1.5789.0816 Flange Bolt M8×16 70 1.862.06 Lock Washer Ø6 71 1.5789.0612 Flange Bolt M6×12 72 5.1900.029 Grounding Line 73 100106.21 Control Panel Assembly 74 5.1810.000 Over Voltage Protector 75 1.823.0514 Screw M5×14 76 5.1800.000 Rectifier 77 1.9074.1.0538.2 Screw/Washer Assembly M5x 78 122.210003.00 Grommet 79 152.15.35.2 Control Panel 80 5.1400.003 Voltage Meter 81 5.1000.004 Ignition Switch	2
65 152.201200.04 Motor Mount II 66 1.5789.0825 Flange Bolt M8×25 67 152.200002.00.2 Support Leg 60 mm 68 152.201400.00 Rubber, Support 69 1.5789.0816 Flange Bolt M8×16 70 1.862.06 Lock Washer Ø6 71 1.5789.0612 Flange Bolt M6×12 72 5.1900.029 Grounding Line 73 100106.21 Control Panel Assembly 74 5.1810.000 Rectifier 75 1.823.0514 Screw M5×14 76 5.1800.000 Rectifier 77 1.9074.1.0538.2 Screw/Washer Assembly M53 78 122.210003.00 Grommet 79 152.15.35.2 Control Panel 80 5.1400.003 Voltage Meter 80 5.1400.004 Ignition Switch	2
66 1.5789.0825 Flange Bolt M8×25 67 152.200002.00.2 Support Leg 60 mm 68 152.201400.00 Rubber, Support 69 1.5789.0816 Flange Bolt M8×16 70 1.862.06 Lock Washer Ø6 71 1.5789.0612 Flange Bolt M6×12 72 5.1900.029 Grounding Line 73 100106.21 Control Panel Assembly 74 5.1810.000 Over Voltage Protector 75 1.823.0514 Screw M5×14 76 5.1800.000 Rectifier 77 1.9074.1.0538.2 Screw/Washer Assembly M5x 78 122.210003.00 Grommet 79 152.15.35.2 Control Panel 80 5.1400.003 Voltage Meter 81 5.1000.004 Ignition Switch	2
67 152.200002.00.2 Support Leg 60 mm 68 152.201400.00 Rubber, Support 69 1.5789.0816 Flange Bolt M8×16 70 1.862.06 Lock Washer Ø6 71 1.5789.0612 Flange Bolt M6×12 72 5.1900.029 Grounding Line 73 100106.21 Control Panel Assembly 74 5.1810.000 Over Voltage Protector 75 1.823.0514 Screw M5×14 76 5.1800.000 Rectifier 77 1.9074.1.0538.2 Screw/Washer Assembly M5x 78 122.210003.00 Grommet 79 152.15.35.2 Control Panel 80 5.1400.003 Voltage Meter 81 5.1000.004 Ignition Switch	2
68 152.201400.00 Rubber, Support 69 1.5789.0816 Flange Bolt M8×16 70 1.862.06 Lock Washer Ø6 71 1.5789.0612 Flange Bolt M6×12 72 5.1900.029 Grounding Line 73 100106.21 Control Panel Assembly 74 5.1810.000 Over Voltage Protector 75 1.823.0514 Screw M5×14 76 5.1800.000 Rectifier 77 1.9074.1.0538.2 Screw/Washer Assembly M5x 78 122.210003.00 Grommet 79 152.15.35.2 Control Panel 80 5.1400.003 Voltage Meter 81 5.1000.004 Ignition Switch	2
69 1.5789.0816 Flange Bolt M8×16 70 1.862.06 Lock Washer Ø6 71 1.5789.0612 Flange Bolt M6×12 72 5.1900.029 Grounding Line 73 100106.21 Control Panel Assembly 74 5.1810.000 Over Voltage Protector 75 1.823.0514 Screw M5×14 76 5.1800.000 Rectifier 77 1.9074.1.0538.2 Screw/Washer Assembly M5x 78 122.210003.00 Grommet 79 152.15.35.2 Control Panel 80 5.1400.003 Voltage Meter 81 5.1000.004 Ignition Switch	1
70 1.862.06 Lock Washer Ø6 71 1.5789.0612 Flange Bolt M6×12 72 5.1900.029 Grounding Line 73 100106.21 Control Panel Assembly 74 5.1810.000 Over Voltage Protector 75 1.823.0514 Screw M5×14 76 5.1800.000 Rectifier 77 1.9074.1.0538.2 Screw/Washer Assembly M5x 78 122.210003.00 Grommet 79 152.15.35.2 Control Panel 80 5.1400.003 Voltage Meter 81 5.1000.004 Ignition Switch	2
71 1.5789.0612 Flange Bolt M6×12 72 5.1900.029 Grounding Line 73 100106.21 Control Panel Assembly 74 5.1810.000 Over Voltage Protector 75 1.823.0514 Screw M5×14 76 5.1800.000 Rectifier 77 1.9074.1.0538.2 Screw/Washer Assembly M5x 78 122.210003.00 Grommet 79 152.15.35.2 Control Panel 80 5.1400.003 Voltage Meter 81 5.1000.004 Ignition Switch	2
72 5.1900.029 Grounding Line 73 100106.21 Control Panel Assembly 74 5.1810.000 Over Voltage Protector 75 1.823.0514 Screw M5×14 76 5.1800.000 Rectifier 77 1.9074.1.0538.2 Screw/Washer Assembly M5x 78 122.210003.00 Grommet 79 152.15.35.2 Control Panel 80 5.1400.003 Voltage Meter 81 5.1000.004 Ignition Switch	2
73 100106.21 Control Panel Assembly 74 5.1810.000 Over Voltage Protector 75 1.823.0514 Screw M5×14 76 5.1800.000 Rectifier 77 1.9074.1.0538.2 Screw/Washer Assembly M5x 78 122.210003.00 Grommet 79 152.15.35.2 Control Panel 80 5.1400.003 Voltage Meter 81 5.1000.004 Ignition Switch	5
74 5.1810.000 Over Voltage Protector 75 1.823.0514 Screw M5x14 76 5.1800.000 Rectifier 77 1.9074.1.0538.2 Screw/Washer Assembly M5x 78 122.210003.00 Grommet 79 152.15.35.2 Control Panel 80 5.1400.003 Voltage Meter 81 5.1000.004 Ignition Switch	1
75 1.823.0514 Screw M5×14 76 5.1800.000 Rectifier 77 1.9074.1.0538.2 Screw/Washer Assembly M5x 78 122.210003.00 Grommet 79 152.15.35.2 Control Panel 80 5.1400.003 Voltage Meter 81 5.1000.004 Ignition Switch	1
76 5.1800.000 Rectifier 77 1.9074.1.0538.2 Screw/Washer Assembly M52 78 122.210003.00 Grommet 79 152.15.35.2 Control Panel 80 5.1400.003 Voltage Meter 81 5.1000.004 Ignition Switch	1
77 1.9074.1.0538.2 Screw/Washer Assembly M52 78 122.210003.00 Grommet 79 152.15.35.2 Control Panel 80 5.1400.003 Voltage Meter 81 5.1000.004 Ignition Switch	2
78 122.210003.00 Grommet 79 152.15.35.2 Control Panel 80 5.1400.003 Voltage Meter 81 5.1000.004 Ignition Switch	1
79 152.15.35.2 Control Panel 80 5.1400.003 Voltage Meter 81 5.1000.004 Ignition Switch	
80 5.1400.003 Voltage Meter 81 5.1000.004 Ignition Switch	1
81 5.1000.004 Ignition Switch	1
Ű	1
	1
82 5.1240.925 AC 25A Breaker, Double Pol- CSA	^{e,} 1
83 1.9074.4.0306.2 Screw/Washer Assembly M3:	<6 4
84 5.1120.026 Receptacle L14-30R, (CSA)	1
85 5.1210.920 AC 20A Breaker, Push Butto	^{n,} 2
86 1.9074.4.0414.1 Screw/Washer Assembly M4	<14 6
87 1.6177.1.04.1 Nut M4	6
88 5.1120.027 Receptacle 5-20R, Duplex, 0	CSA 2
89 1.5783.0622.3 Bolt M6×22, Green	1
90 1.6175.06.3 Nut M6, Green	2
91 1.93.06.3 Washer Ø6, Green	2
92 1.97.1.06.3 Lock Washer Ø6, Green	2
93 152.210003.01 Wire Jacket, Control Box, CS	A 1
94 5.1310.004 Conduit (Metal, 180 mm)	1
95 152.210003.03 Plug, Control Box, CSA	1
96 152.210002.10 Control Box	1
97 100106.21.10 Wire Assembly	

SPECIFICATIONS

Engine Parts Diagram



6

#	Part Number	Description	Qty
1	21.061300.00	Recoil Handle	1
2	1.5789.0608	Flange Bolt M6×8	4
3	46.061100.00.2	Recoil Starter Cover, Black	1
4	45.060005.00	Recoil Starter Spring	1
5	45.061102.00	Recoil Starter Reel	1
6	2.10.003	Rope (Ø5×1550)	1
7	45.060003.00	Spring, Ratchet	2
8	45.060002.00	Starter Ratchet (Iron)	2
9	45.060009.00	Spring, Ratchet Guide	1
10	45.060007.00	Guide, Ratchet	1
11	45.060008.00	Screw, Ratchet Guide	1
12	1.5789.0612	Flange Bolt M6×12	12
13	2.05.005	Clamp (Ø6)	2
14	46.080100.01.48	Fan Cover, Yellow	1
15	2.02.007	Nut (M16×1.5)	1
16	1.5789.0629	Flange Bolt M6×29	2
17	45.060001.00	Pulley, Starter	1
18	46.123000.01	Coil, Ignition	1
19	45.080001.00	Cooling Fan	1
20	46.120100.03	Flywheel (EPA)	1
21	2.11.007	Oil Seal (Ø35ר52×8)	2
22	2.05.050	Wire Clip, 100 mm	1
23	45.030032.00	Sheath, Wire	1
24	2.03.023	Washer (Ø12.5ר20×2)	2
25 26	46.030100.00 45.127000.02	Crankcase Oil Level Sensor	1
20	1.5789.0615	Flange Bolt M6×15	1 2
28	1.276.6202	Bearing 6202	2
29	47.050006.00	Weight Balancer	1
30	45.050100.14	Crankshaft	1
31	46.030008.00	Gasket, Crankcase Cover	1
32	2.04.001	Dowel Pin (Ø9×14)	2
33	46.080600.00	Air Guide, Right Side	1
34	1.276.6207	Bearing 6207	1
35	46.031000.01.48	Oil Dipstick Assembly, Yellow	1
36	45.030007.00	Cover, Crankcase	1
37	1.5789.0840.0.8	Flange Bolt M8×40	7
38	2.03.021.1	Washer (Ø6.4ר13×1), Black	1
39	45.110013.00	Shaft, Governor Gear	1
40	45.110100.00	Gear, Governor	1
41	21.110011.00	Clip, Governor Gear	1
42	45.110012.00	Bushing, Governor Gear	1
43	47.050200.00	Connecting Rod	1
44	46.050005.01	Piston	1
45	2.09.004	Circlip (Ø21ר1)	2
46	45.050003.00	Pin, Piston	1
47	46.050303.01	Ring, Oil	1
48	46.050302.01	Ring, Second Piston	1
49	46.050301.01	Ring, First Piston	1
50	2.04.004	Dowel Pin (Ø12×20)	2
51	46.030009.00	Gasket, Cylinder Head	1
52	46.080400.00	Air Guide, Lower	1
53	46.010100.00	Cylinder Head	1
54	2.01.010	Stud Bolt M8×35	2
55	2.15.002(F6RTC)	Spark Plug (F6RTC)	1

#	Part Number	Description	Qty
56	2.08.014	Flange Bolt M10×80	4
57	46.020002.00	Gasket, Cylinder Head Cover	1
58	46.021000.00	Cylinder Head Cover	1
59	45.020001.02	Breather Tube	1
60	45.020100.00	Bolt, Cylinder Head Cover	1
61	2.08.039	Drain Bolt (M12×1.25×15)	2
62	46.041000.00	Camshaft (EPA)	1
63	45.040013.00	Lifter, Valve	2
64	45.040002.00	Valve, Intake	1
65	45.040006.00	Valve, Exhaust	1
66	46.040005.00	Push Rod	2
67	45.040015.00	Retainer, Valve Spring	2
68	45.040017.00	Oil Seal, Valve	2
69	45.040003.00	Valve Spring	2
70	23.040010.00	Bolt, Rocker Arm	2
71	45.040001.00	Retainer, Intake Valve Spring	1
72	45.040007.00	Retainer, Exhaust Valve Spring	1
73	45.040008.00	Rotator, Exhaust Valve	1
74	46.040004.00	Guide Plate, Push Rod	1
75	46.040016.00	Shaft, Rocker Arm	1
76	46.040201.00	Retainer, Rocker Arm	1
77	46.040009.00	Rocker Arm, Intake Valve	1
78	46.040018.00	Rocker Arm, Exhaust Valve	1
79	1.97.1.06	Washer Ø6	2
80	22.040012.00	Screw, Valve Adjustment	2
81	1.6177.1.06	Flange Lock Nut M6	2
82	21.040021.00	Nut, Lock (M6×0.5)	2
83	2.01.008	Stud Bolt (M6×M8×105)	2
84	46.130002.20	Gasket, Insulator	1
85	45.130001.01	Insulator, Carburetor	1
86	46.130003.00	Gasket, Carburetor	1
87	46.131000.21	Carburetor	1
88	46.131000.25 46.130004.20	Gasket, Air Cleaner	1
89	1.6177.06	Flange Nut M6	3
90	46.091100.04	Base, Air Cleaner	1
91	45.091002.20	Seal, Air Cleaner	1
92	45.091001.20	Separator, Air Cleaner	1
92	45.091003.20	Element, Air Cleaner	1
94	46.091200.04	Cover, Air Cleaner	1
95	45.110001.00	Shaft, Governor Arm	1
96	2.03.019	Washer (Ø8.2ר17×0.8)	1
97	2.11.006	Oil Seal (Ø7ר14×5)	1
98	45.110008.00	Pin, Shaft	1
99	45.110003.00	Arm, Governor	1
100	2.08.040	Bolt, Governor Arm (M6×21)	1
101	45.110006.00	Rod, Governor	1
102	45.110005.00	Spring, Throttle Return	1
103	45.110007.00	Spring, Governor	1
104	46.080300.20	Air Guide, Upper	1
105	46.131017.21	Main Jet, Standard	1
105	46.131017.21.01	Main Jet, Altitude	1
106	46.091000.04	Air Cleaner Assembly	1
107	46.061000.00	Recoil Assembly	1

TROUBLESHOOTING

Problem	Cause	Solution
Generator will not start	No fuel	Add fuel
	Faulty spark plug	Replace spark plug
	Unit loaded during start up	Remove load from unit
Generator will not start; Generator starts but runs roughly	Low oil level	Fill crankcase to the proper level
		Place generator on a flat, level surface
	Choke in the wrong position	Adjust choke
	Spark plug wire loose	Attach wire to spark plug
Generator shuts down during operation	Out of fuel	Fill fuel tank
	Low oil level	Fill crankcase to the proper level. Place generator on a flat, level surface
Generator cannot supply enough power or overheating	Generator is overloaded	Review load and adjust. See "Power Management"
	Insufficient ventilation	Check for air restriction. Move to a well ventilated area
No AC output	Cable not properly connected	Check all connections
	Connected device is defective	Replace defective device
	Circuit breaker is open	Reset circuit breaker
	Faulty brush assembly	Replace brush assembly (Service Center)
	Faulty AVR (auto voltage regulator)	Replace AVR (Service Center)
	Loose wiring	Inspect and tighten wiring connections
	Other	Contact the help line
Generator gallops	Engine governor defective	Contact the help line
Repeated circuit breaker tripping	Overload	Review load and adjust. See "Power Management"
	Faulty cords or device	Check for damaged, bare or frayed wires. Replace defective device

For further technical support:

Technical Service Mon – Fri 8:30 AM – 5:00 PM (PST/PDT) Toll Free: 1-877-338-0999 tech@championpowerequipment.com

WARRANTY*

CHAMPION POWER EQUIPMENT 3 YEAR LIMITED WARRANTY

Warranty Qualifications

Champion Power Equipment (CPE) will register this warranty upon receipt of your Warranty Registration Card and a copy of your sales receipt from one of CPE's retail locations as proof of purchase. Please submit your warranty registration and your proof of purchase within ten (10) days of the date of purchase.

Repair/Replacement Warranty

CPE warrants to the original purchaser that the mechanical and electrical components will be free of defects in material and workmanship for a period of three years (parts and labor) from the original date of purchase and 270 days (parts and labor) for commercial and industrial use. Transportation charges on product submitted for repair or replacement under this warranty are the sole responsibility of the purchaser. This warranty only applies to the original purchaser and is not transferable.

Do Not Return The Unit To The Place Of Purchase

Contact CPE's Technical Service and CPE will troubleshoot any issue via phone or e-mail. If the problem is not corrected by this method, CPE will, at its option, authorize evaluation, repair or replacement of the defective part or component at a CPE Service Center. CPE will provide you with a case number for warranty service. Please keep it for future reference. Repairs or replacements without prior authorization, or at an unauthorized repair facility, will not be covered by this warranty.

Warranty Exclusions

This warranty does not cover the following repairs and equipment:

Normal Wear

Products with mechanical and electrical components need periodic parts and service to perform well. This warranty does not cover repair when normal use has exhausted the life of a part or the equipment as a whole.

Installation, Use and Maintenance

This warranty will not apply to parts and/or labor if the product is deemed to have been misused, neglected, involved in an accident, abused, loaded beyond the product's limits, modified, installed improperly or connected incorrectly to any electrical component. Normal maintenance is not covered by this warranty and is not required to be performed at a facility or by a person authorized by CPE.

Other Exclusions

This warranty excludes:

- Cosmetic defects such as paint, decals, etc.
- Wear items such as filter elements, o-rings, etc.
- Accessory parts such as starting batteries, and storage covers.
- Failures due to acts of God and other force majeure events beyond the manufacturer's control.
- Problems caused by parts that are not original Champion Power Equipment parts.

When applicable, this warranty does not apply to products used for prime power in place of a utility.

Limits of Implied Warranty and Consequential Damage

Champion Power Equipment disclaims any obligation to cover any loss of time, use of this product, freight, or any incidental or consequential claim by anyone from using this product. THIS WARRANTY AND THE ATTACHED U.S. EPA, CARB and/or ECCC EMISSION CONTROL SYSTEM WARRANTIES (WHEN APPLICABLE) ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

A unit provided as an exchange will be subject to the warranty of the original unit. The length of the warranty governing the exchanged unit will remain calculated by reference to the purchase date of the original unit.

This warranty gives you certain legal rights which may change from state to state or province to province. Your state or province may also have other rights you may be entitled to that are not listed within this warranty.

Contact Information

Address

Champion Power Equipment, Inc. Customer Service 12039 Smith Ave. Santa Fe Springs, CA 90670 USA www.championpowerequipment.com

Customer Service

Mon – Fri 8:30 AM – 5:00 PM (PST/PDT) Toll Free: 1-877-338-0999 info@championpowerequipment.com Fax no.: 1-562-236-9429

Technical Service

Mon – Fri 8:30 AM – 5:00 PM (PST/PDT) Toll Free: 1-877-338-0999 tech@championpowerequipment.com 24/7 Tech Support: 1-562-204-1188

*Except as otherwise stipulated in any of the following enclosed Emission Control System Warranties (when applicable) for the Emission Control System: U.S. Environment Protection Agency (EPA), California Air Resources Board (CARB) and/or Environment and Climate Change Canada (ECCC). Whichever warranty applies for the longer period, either this 3 year limited warranty or the applicable Emission Control System Warranty, shall supersede the other.

Champion Power Equipment, Inc (CPE) and Environment and Climate Change Canada (ECCC) Emission Control System Warranty

Your Champion Power Equipment (CPE) engine complies with Environment and Climate Change Canada (ECCC) emission regulations.

YOUR WARRANTY RIGHTS AND OBLIGATIONS:

CPE is pleased to explain the Emission Control Systems Warranty on your 2017 small off-road engine. New engines must be designed, built and equipped, at the time of sale, to meet ECCC regulations for small non-road engines. CPE must warrant the emission control system on your small off-road engine for the period of time listed below, provided there has been no abuse, neglect, unapproved modification, or improper maintenance of your small off-road engine.

Your emission control system may include parts such as the carburetor, fuel-injection system, the ignition system, catalytic converter and fuel lines. Also included may be hoses, belts, connectors and other emission related assemblies. Where a warrantable condition exits, CPE will repair your small off-road engine at no cost to you including diagnosis, parts and labour.

MANUFACTURER'S EMISSION CONTROL SYSTEM WARRANTY COVERAGE:

This emission control system is warranted for two years, subject to provisions set forth below. If, during the warranty period, emission related part on your engine is defective in materials or workmanship, the part will be repaired or replaced by CPE.

OWNER WARRANTY RESPONSIBILITIES:

As the small off-road engine owner, you are responsible for the performance of the required maintenance listed in your Owner's Manual. CPE recommends that you retain all your receipts covering maintenance on your small off-road engine, but CPE cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.

As the small off-road engine owner, you should however be aware that CPE may deny you warranty coverage if your small, off-road engine or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

You are responsible for presenting your small off-road engine to an Authorized CPE service outlet, CPE dealer or CPE, Santa Fe Springs, CA., USA as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.

If you have any questions regarding your warranty rights and responsibilities, you should contact:

Champion Power Equipment, Inc. Customer Service 12039 Smith Ave. Santa Fe Springs, CA 90670 USA Tel: 1-877-338-0999 tech@championpowerequipment.com

EMISSION CONTROL SYSTEM WARRANTY

The following are specific provisions relative to your Emission Control System Warranty Coverage.

Emission Control System Warranty (ECS Warranty):

1. APPLICABILITY: The ECS Warranty Period shall begin on the date the new engine or equipment is delivered to its original, end-use purchaser, and shall continue for 24 consecutive months thereafter.

2. GENERAL EMISSIONS WARRANTY COVERAGE

CPE warrants to the original, end-use purchaser of the new engine or equipment and to each subsequent purchaser that each of its small off-road engines is:

a. Designed, built and equipped so as to conform at the time of sale with applicable regulations under the Canadian Environmental Protection Act, 1999 (CEPA 1999).

b. Free from defects in materials and workmanship that cause the failure of a warranted part to be identical in all material respects to the part as described in the engine manufacturer's application for certification for a period of two years.

3. THE WARRANTY ON EMISSION-RELATED PARTS WILL BE INTERPRETED AS FOLLOWS:

a. Any warranted part that is not scheduled for replacement as required maintenance in the Owners Manual shall be warranted for the ECS Warranty Period. If any such part fails during the ECS Warranty Period, it shall be repaired or replaced by CPE according to Subsection "d" below. Any such part repaired or replaced under the ECS Warranty shall be warranted for any remainder of the ECS Warranty Period.

b. Any warranted, emissions-related part which is scheduled only for regular inspection as specified in the Owners Manual shall be warranted for the ECS Warranty Period. A statement in such written instructions to the effect of "repair or replace as necessary", shall not reduce the ECS Warranty Period. Any such part repaired or replaced under the ECS Warranty shall be warranted for the remainder of the ECS Warranty Period.

c. Any warranted, emissions-related part which is scheduled for replacement as required maintenance in the Owner's Manual shall be warranted for the period of time prior to the first scheduled replacement point for that part. If the part fails prior to the first scheduled replacement, the part shall be repaired or replaced by CPE according to Subsection "d" below. Any such emissions-related part repaired or replaced under the ECS Warranty, shall be warranted for the remainder of the ECS Warranty Period prior to the first scheduled replacement point for such emissions-related part.

d. Repair or replacement of any warranted, emissions-related part under this ECS Warranty shall be performed at no charge to the owner at a CPE Authorized Service Outlet.

e. The owner shall not be charged for diagnostic labour which leads to the determination that a part covered by the ECS Warranty is in fact defective, provided that such diagnostic work is performed at a CPE Authorized Service Outlet.

f. CPE shall be liable for damages to other original engine components or approved modifications proximately caused by a failure under warranty of an emission-related part covered by the ECS Warranty.

g. Throughout the ECS Warranty Period, CPE shall maintain a supply of warranted emissionrelated parts sufficient to meet the expected demand for such emission-related parts.

h. Any CPE Authorized and approved emission-related replacement part may be used in the performance of any ECS Warranty maintenance or repair and will be provided without charge to the owner. Such use shall not reduce CPE's warranty obligation.

i. Unapproved add-on or modified parts may not be used to modify or repair a CPE engine. Such use voids this ECS Warranty and shall be sufficient grounds for disallowing an ECS Warranty claim. CPE shall not be liable hereunder for failures of any warranted parts of a

CPE engine caused by the use of such an unapproved add-on or modified part.

EMISSION-RELATED PARTS INCLUDE THE FOLLOWING: (using those portions of the list applicable to the engine)

Systems covered by this warranty	Parts description	
Fuel Metering System	Fuel regulator, carburetor and internal parts	
Air Induction System	Air cleaner, intake manifold	
Ignition System	Spark plug and parts, magneto ignition system	
Exhaust System	Exhaust manifold, catalytic converter	
Miscellaneous Parts	Tubing, fittings, seals, gaskets, and clamps associated with these listed systems.	
Evaporative Emissions	Fuel tank, fuel cap, fuel line, fuel line fittings, clamps, pressure relief valves, control valves, control solenoids, electronic controls, vacuum control diaphragms, control cables, control linkages, purge valves, vapour hoses, liquid/ vapour separator, carbon canister, canister mounting brackets, carburetor purge port connector	

TO OBTAIN WARRANTY SERVICE:

You must take your CPE engine or the product on which it is installed, along with your warranty registration card or other proof of original purchase date, at your expense, to any Champion Power Equipment dealer who is authorized by Champion Power Equipment, Inc. to sell and service that CPE product during his normal business hours. Claims for repair or adjustment found to be caused solely by defects in material or workmanship will not be denied because the engine was not properly maintained and used.

If you have any questions regarding your warranty rights and responsibilities, or to obtain warranty service, please write or call Customer Service at Champion Power Equipment, Inc.

Champion Power Equipment, Inc. 12039 Smith Ave. Santa Fe Springs, CA 90670 USA 1-877-338-0999 Attn: Customer Service tech@championpowerequipment.com