

**OWNER'S MANUAL** 



# 3 in. (7.6 cm) Chipper-Shredder



MODEL NUMBER 91050

12039 Smith Ave. Santa Fe Springs, CA 90670 USA / 1-877-338-0999 www.championpowerequipment.com

SAVE THESE INSTRUCTIONS Important Safety Instructions are included in this manual.


REV 91050-20210128

#### AN IMPORTANT MESSAGE ABOUT TEMPERATURE:

Your Champion Power Equipment product is designed and rated for continuous operation at ambient temperatures up to 40°C (104°F). When your product is needed your product may be operated at temperatures ranging from -15°C (5°F) to 50°C (122°F) for short periods. If the product is exposed to temperatures outside this range during storage, it should be brought back within this range before operation. In any event, the product must always be operated outdoors, in a well-ventilated area and away from doors, windows and other vents.



**Parts Ordering:** Mon – Fri 8:30 AM – 5:00 PM (PST/PDT) Toll Free: 1-877-338-0999



# 3 in. (7.6 cm) Chipper-Shredder

# TABLE OF CONTENTS

Introduction	. 1
Manual Conventions	. 2
Safety Rules	. 3
Training	. 5
Preparation	. 5
Operation	. 6
Maintenance and Storage	. 6
Controls and Features	. 7
Chipper-shredder	. 7
Parts Included	. 8
Assembly	. 9
Unpacking	. 9
1) Install the Shredder Chute	. 9
2) Install the Handle	
3) Install the Chipper Chute	
4) Install the Chute Deflector	10
Collection Bag	
Add Engine Oil	
Add Engine Fuel	
Operation	
Chipper-shredder Location	
Work Area	
Before Each Use Inspect the Chipper-shredder	14
Starting the Engine	14
Chipper-shredder Operation	15
Chipping and Shredding Tips	16
Chipping	16
Shredding	16
Clearing the Shredding Chute	17
Emptying the Collection Bag	
Stopping the Engine	
Operation at High Altitude	18

Maintenance and Storage	18
Engine Maintenance	18
Oil	18
Spark Plugs	19
	19
	19
	19
-	20
Blade Sharpening	20
	21
Storage	21
Chipper-shredder Storage	22
Engine Stored for Less than 30 Days	22
	22
Specifications	23
-	23
Engine Specifications	23
Fuel	23
Oil	23
	23
	23
An Important Message About Temperature	23
Troubleshooting	24

## INTRODUCTION

#### Introduction

Congratulations on your purchase of a Champion Power Equipment product. Champion Power Equipment and Champion Engine Technology designs, builds, and supports all of our products to strict specifications and guidelines. With proper product knowledge, safe use, and regular maintenance, this product should bring years of satisfying service.

Every effort has been made to ensure the accuracy and completeness of the information in this manual, and we reserve the right to change, alter and/or improve the product and this document at any time without prior notice.

Since CPE/CET highly value how our products are designed, manufactured, operated and are serviced, and also highly value your safety and the safety of others, we would like you to take the time to review this product manual and other product materials thoroughly and be fully aware and knowledgeable of the assembly, operation, dangers and maintenance of the product before use. Fully familiarize yourself, and make sure others who plan on operating the product fully familiarize themselves too, with the proper safety and operation procedures before each use. Please always exercise common sense and always error on the side of caution when operating the product to ensure no accidents, property damage, or injury occurs. We want you to continue to use and be satisfied with your CPE/CET product for years to come.

Record the model and serial numbers as well as date and place of purchase for future reference. Have this information available when ordering parts and when making technical or warranty inquiries.

	1-877-338-0999
	Model Number
	91050
	Serial Number
	Date of Purchase
	Purchase Location
For <b>(</b>	Dil Type see 'Add Engine Oil' section. For Fuel Type see 'Add Fuel' section.

This manual uses the following symbols to help differentiate between different kinds of information. The safety symbol is used with a key word to alert you to potential hazards in operating and owning power equipment. Follow all safety messages to avoid or reduce the risk of serious injury or death.

### \land DANGER

DANGER indicates an imminently hazardous situation which, if not avoided, **will** result in death or serious injury.

# **MWARNING**

WARNING indicates a potentially hazardous situation which, if not avoided, **could** result in death or serious injury.

# **!** CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, **may** result in minor or moderate injury.

# CAUTION

CAUTION used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, **may** result in property damage.

### **NOTE**

If you have questions regarding your chippershredder, we can help. Please call our help line at **1-877-338-0999.** 

# **SAFETY RULES**

# \land DANGER

Read this manual thoroughly, and understand all safety rules before operating the chipper-shredder. Become familiar with the product and know how to stop the product immediately if needed. Failure to follow safety instructions and familiarize one's self with product operation could result in serious property damage, injury or death.

# \land DANGER

Always disconnect the spark plug wire during times of inactivity, cleaning and maintenance. This will prevent any accidental start up that may cause damage or injury.

# \land DANGER

Engine exhaust contains carbon monoxide, a colourless. odourless, poison gas. Breathing carbon monoxide will cause nausea, dizziness, fainting or death. If you start to feel dizzy or weak, get to fresh air immediately.

Run the motor outdoors only in a well ventilated area. DO NOT operate the engine inside any buildings or enclosures.

DO NOT allow exhaust fumes to enter a confined area through windows, doors, vents or other openings. **DANGER CARBON MONOXIDE**, using an engine indoors **CAN KILL YOU IN MINUTES**.

# \land DANGER

Hands, feet, hair, clothing and / or accessories can be caught in moving rotating parts and cause a traumatic amputation or severe laceration.

Keep hands and feet away from rotating parts. Tie up long hair and remove jewellery. Operate equipment with guards in place. DO NOT wear loose-fitting clothing, dangling drawstrings or items that could become caught.

# \land DANGER

Sparks can result in fire or electrical shock.

#### When servicing the engine:

Disconnect the spark plug wire and place it where it cannot contact the plug. DO NOT check for spark with the plug removed. Use only approved spark plug testers.

# A WARNING

Running engines produce heat. Severe burns can occur on contact. Combustible material can catch fire on contact.

DO NOT touch hot surfaces. Avoid contact with hot exhaust gases. Allow equipment to cool before touching. Maintain at least 3 ft. (91.4 cm) of clearance on all sides to ensure adequate cooling. Maintain at least 5 ft. (1.5 m) of clearance from combustible materials.

## \land WARNING

#### Child, Pet and Bystander Hazard

Do not allow children, pets or bystanders near the work area or location of the chipper-shredder. This can create potential distractions and safety hazards. Accidents, damage and injury could occur. A minimum distance of 75 ft. (22.9 m) from the chipper-shredder is recommended. Projectiles can also fly haphazardly in the work area. Only a qualified adult with complete working knowledge of the product and safety rules should operate the chipper-shredder and be in the work area.

### \land DANGER

Fuel and fuel vapours are highly flammable and extremely explosive.

Fire or explosion can cause severe burns or death. Unintentional startup can result in entanglement, traumatic amputation or laceration.

#### When adding or removing fuel:

Turn the engine off and let it cool for at least two minutes before removing the fuel cap. Loosen the cap slowly to relieve pressure in the tank. Only fill or drain fuel outdoors in a well-ventilated area. DO NOT pump gas directly into the chippershredder at the gas station. Use an approved container to transfer the fuel to the chippershredder.

DO NOT overfill the fuel tank.

Always keep fuel away from sparks, open flames, pilot lights, heat and other sources of ignition. DO NOT light or smoke cigarettes.

#### When starting the engine:

DO NOT attempt to start a damaged engine. Make certain that the gas cap, air filter, spark plug, fuel lines and exhaust system are properly in place. Allow spilled fuel to evaporate fully before attempting to start the engine.

Make certain that the chipper-shredder is resting firmly on level ground.

#### When operating the chipper-shredder:

DO NOT move or tip the chipper-shredder during operation.

DO NOT tip the chipper-shredder or allow fuel or oil to spill.

#### When transporting or servicing the chipper-shredder:

Make certain that the fuel shutoff valve is in the off position and the fuel tank is empty. Disconnect the spark plug wire.

#### When storing the chipper-shredder:

Store away from sparks, open flames, pilot lights, heat and other sources of ignition.

### / WARNING

#### Keep Operator Work Zone Clear

Keep work zone clear of debris while working to ensure safe footing.

### ∕<u>∧</u> WARNING

#### Projectile Hazard

Pieces of debris may be ejected from the chippershredder while operating. **Be alert.** 

# \land DANGER

Always wear proper clothing and safety gear.

Close fitting clothing and safety approved eye protection must be wore at all times around the chipper-shredder. Wear boots or sturdy shoes that will improve footing around slippery surfaces.

### A WARNING

Rapid retraction of the starter cord will pull hand and arm towards the engine faster than you can let go. Unintentional startup can result in entanglement, traumatic amputation or laceration. Broken bones, fractures, bruises or sprains could

result.

When starting engine, pull the starter cord slowly until resistance is felt and then pull rapidly to avoid kickback.

## A CAUTION

Improper treatment or use of the chipper-shredder can damage it, shorten its life and void your warranty.

Use the chipper-shredder only for intended uses. Operate only on level surfaces. DO NOT expose chipper-shredder to excessive moisture, dust, or dirt.DO NOT allow any material to block the cooling slots.

DO NOT use the engine if:

- Equipment sparks, smokes or emits flames
- Equipment vibrates excessively
- Equipment makes unusual sounds
- Equipment is damaged

# SAFETY RULES

### Training

- 1. Read the Operator's Manual completely before attempting to use this chipper-shredder.
- 2. Do not allow anyone to operate your chippershredder who has not read the Operator's Manual or has not been instructed on the safe use of the chipper-shredder.
- 3. Never allow children or untrained adults to operate this machine.
- 4. Many accidents occur when more than one (1) person operates the chipper-shredder. If a helper is assisting, never actuate controls until helper is clear of the area.
- 5. Never allow anyone to ride on the machine.
- 6. Never transport cargo on the chipper-shredder.
- Projectiles can exit the chipper-shredder at high velocities. Therefore, the following instructions should be heeded at all times.
  - a. Never operate the unit on hardened ground, such as asphalt or concrete.
  - b. Never operate the unit close to any buildings or walls.
  - c. Do not allow children, pets, bystanders, and assistants to be within 75 ft. (22.9 m) of the unit during operation.
  - d. Do not lean directly over any chute, entry or exit, during operation.
- 8. Keep the operator zone and adjacent area clear for safe, secure footing.
- 9. If your chipper-shredder is equipped with an internal-combustion engine and intended for use near any unimproved forest, brush, or grass covered land, the engine exhaust should be equipped with a spark arrestor. Make sure you comply with local, state, and federal codes. Take appropriate fire-fighting equipment with you.
- Chipper-shredders should be used only for chipping branches 3 in. (7.6 cm) or less in diameters or shredding vegetation with small diameter branches. Do not use for other purposes.
- 11. Always make sure the spark plug wire is disconnected from the engine when not in use, and before cleaning or maintenance.

### Preparation

- 1. Be thoroughly familiar with all controls and with proper use of the equipment.
- 2. Make sure the spark plug wire is disconnected until operation.
- 3. Safety Gear:
  - a. Always wear safety shoes or heavy boots when operating the machine.
  - b. Always wear safety glasses or goggles when operating the machine.
  - c. Never wear jewelry or loose-fitting clothing that might become entangled in moving or rotating parts of the machine.
  - d. Always wear hearing protection.
  - e. Tie back long hair or anything that will dangle and may get entangled.
- 4. Inspection:
  - a. Make sure the spark plug wire has been fully removed and the unit is grounded.
  - b. Make sure the chutes, chambers, and intakes/ exits are all clean and free of any debris.
  - c. Make sure the work area is clean and has no obstacles or distractions.
  - d. Make sure all connections and parts are secure and undamaged.
  - e. Make sure collection bag is fully connected and secure.
  - f. Make sure material to be chipped is less than 3 in. (7.6 cm) in diameter. Branches to be chipped can be pruned down.
  - g. Make sure material to be chipped or shredded is not damp or wet.
- 5. Check to make sure the chipper-shredder is on a level surface that is not asphalt, concrete or harden ground. Block the wheels and ensure support leg is secure to prevent unintended movement of the chipper-shredder during operation.
  - a. Always operate the chipper shredder from the manufacturer's indicated operator zone.
- 6. Fuel:
  - a. Use an approved fuel container.
  - b. Never add fuel to a running or hot engine.
  - c. Fill fuel tank outdoors with extreme care. Never fill fuel tank indoors.
  - d. Replace gasoline cap securely and clean up any spilled fuel.

### **Operation**

- 1. Before starting this chipper-shredder, review all safety rules. Failure to follow these rules may result in serious injury to the operator or bystanders.
- Be sure to confirm all connections are tight before each use. It is possible for connections to vibrate loose over time.
- 3. Never leave the machine unattended with the power source operating.
- 4. Never operate the machine when under the influence of alcohol, drugs or medication.
- 5. The machine owner should instruct all operators in safe chipper-shredder operation.
- 6. Always operate the chipper-shredder with all safety equipment in place and all controls properly adjusted for safe operation.
- 7. Always operate the chipper-shredder at manufacturer's recommended speed.
- 8. Always keep hands and feet clear of moving parts.
- 9. When loading the chipper-shredder, never place your hands inside or on the sides of the chutes, chambers, or intake. Never place your hands or any part of your body between the material and any part of the chipper-shredder.
  - a. Never attempt to chip more than one (1) branch at a time, this may cause the chute, chamber or intake to become clogged.
  - b. Never attempt to use your hand, foot or any body part to unclog the chipper-shredder.
  - c. Only attempt to unclog with a small diameter stick that can get chipped.
  - d. If a major clog occurs; turn the fuel valve off and let the unit run until dry, turn off the engine, let the unit cool down, unplug the spark plug wire and take apart the unit to see where the clog has occurred. Remove clog before further operation.
- 10. Only chip branches 3 in. (7.6 cm) or less in diameter.
- 11. Only shred dry or slightly damp material. Never attempt to shred material that is wet, as this may cause clogging to occur.
- 12. Use only your hand to operate the chipper-shredder controls.
- 13. Do not refuel the engine until it has cooled for several minutes.


#### Maintenance and Storage


- Always shut off the power source and disconnect the spark plug wire and ground the engine, while repairing or adjusting the unit.
- 2. Clean debris, shrubbery and chaff from the engine cylinder, cylinder head fins, blower house rotation screen, and muffler areas. If the engine is equipped with a spark arrestor muffler, clean and inspect it regularly (follow manufacturer's service instructions). Replace, if damaged.
- 3. Never store the unit with fuel in the tank. Fumes might reach an open flame spark. Allow the engine to cool before storing in any enclosure.
- 4. Clear debris from moveable parts, but only when the engine is off, the fuel valve is in the "OFF" position, and the spark plug wire is disconnected.
- 5. Check to be sure all nuts and bolts are tight to assure the equipment is in safe working condition.

# **CONTROLS AND FEATURES**

Read this owner's manual before operating your chipper-shredder. Familiarize yourself with the location and function of the controls and features. Save this manual for future reference.

### **Chipper-shredder**





- (1) Choke
- (2) Engine 338cc, OHV, 4-stroke, air cooled.
- (3) Upper Shredder Chute place shreddable material in this chute.
- (4) Lower Shredder Chute
- (5) Handle
- (6) Chipper Chute place chippable material in this chute.


- (7) Wheels 12 in. (30.5 cm) never flat.
- (8) Collection Bag attach to chute deflector to collect material.
- (9) Chute Deflector chipped or shredded material will exit from this.
- (10) Support Leg with Vibration Mounts used to help stabilize the unit.
- (11) Flail Housing housing for chipper-shredder blades.

# **CONTROLS AND FEATURES**

### **Parts Included**

Your 91050 gasoline powered chipper-shredder ships with the following parts:

_	Collection Bag - 2 Bushel (70 L) Capacity	1
_	Oil Funnel	1



# ASSEMBLY

Your chipper-shredder requires some assembly. This unit ships from our factory without oil. It must be properly serviced with fuel and oil before operation.


If you have any questions regarding the assembly of your chipper-shredder, call our help line at 1-877-338-0999. Please have your serial number and model number available.


### Unpacking

- 1. Set the shipping crate on a solid, flat surface
- 2. Carefully cut the shipping bands and remove lid of shipping crate.
- 3. Locate all hardware before beginning assembly.

### 1) Install the Shredder Chute

 Align the holes in the upper shredder chute (#44) with the holes in the lower shredder chute (#50). (A)





- Insert M6x15 bolt (#45) into the hole of the chutes, from top to bottom direction. (B)
- 3. Secure bolt with washer (#11) and lock nut (#12).
- 4. Tighten till secure. Do not over tighten.
- 5. Repeat step 2-4 for all holes in the chutes.

# **NOTE**

Make sure chutes are fully secured with all the holes aligned and filled with bolts. If parts are damaged or missing do not use the unit until replacement parts have been obtained.


### 2) Install the Handle

- 1. Insert handle (#38) into the brackets on the lower shredder chute.
- Secure the handle with the M8x35 bolt (#37), lock washer (#24) and washer (#13), and then through the handle on each side.

NOTE: Handle has a threaded and unthreaded hole on each end. Threaded hole goes on the hopper side. This will allow the bolt to tighten properly when assembled.

3. Tighten until secure. Do not over tighten.

Install the Handle Cont'd.




### 3) Install the Chipper Chute

1. Remove bolt used to secure the support bracket to chute.

### **NOTE**

Only remove bolt, leave bracket in position

- Line up the upper chipper chute (#17) with the rubber blocker (#19), and with the lower chipper chute (#20). (A)
- Once aligned, insert bolt (qty. 4) M6x20 (#18) through the hole in the upper and lower chipper chute (Being sure to re-attach support bracket to chute assembly). Insert bolt from top to bottom direction. (B)
- Secure bolt with washer (#11) and lock nut (#12). (B)
- 5. Tighten till secure. Do not over tighten.
- 6. Repeat step 2-4 for all holes in the chutes.





# WARNING

Make sure the rubber blocker (#19) is secure between the top and bottom chutes. Do not operate unit if blocker is damaged or missing.

### 4) Install the Chute Deflector

- Align the chute deflector (#36) and the hinge spacers (#35) up with the hinge mounting holes on the flailing housing. (A)
- Slide bolt M6x100 (#48) through the hinge mounting holes, hinge spacers, and chute deflector.
- 3. Secure with lock nut (#12). Tighten. Do not overtighten.
- 4. Slide knob bolt (#34) through lock washer (#24) and washer (#13) and then through chute deflector and lower flailing housing assembly.
- 5. Tighten knob bolt. Do not overtighten.
- 6. Repeat for second knob bolt.





### **Collection Bag**

The collection bag can be attached and removed from the chute deflector using the adjustable drawstring. It is recommended to be attached before operation and removed before completely full, after operation, or before storage. The collection bag will collect up to 2 bushels (70 L) of material.

## **MWARNING**

Before operation, ensure the adjustable drawstring is tight around the chute deflector and secure.

### A WARNING

Once the collection bag appears to be almost full, it is recommended to empty it. This will help to keep the bag from becoming dislodged from the deflector chute and also to keep the bag from bursting. Do not allow the collection bag to become dislodged from the deflector chute during operation. If this occurs stop operation at once and let unit cool before reconnecting the collection bag. Only empty the collection bag when the engine is off and the spark plug has been disconnected.

### **NOTE**

Always inspect the collection bag prior to use. Do not use a frayed, worn, or damaged collection bag.

# ASSEMBLY

### Add Engine Oil

### **!** CAUTION

DO NOT attempt to crank or start the engine before it has been properly filled with the recommended type and amount of oil. Damage to the chippershredder as a result of failure to follow these instructions will void your warranty.


# **NOTE**

The recommended oil type is 10W-30 automotive oil.

- 1. Place the chipper-shredder on a flat, level surface.
- 2. Remove oil fill cap/dipstick to add oil.
- 3. Add up to 1.2 qt. (1.1 L) of oil (not included) and replace oil fill cap/dipstick. DO NOT OVERFILL.
- 4. Check engine oil level daily and add as needed.

# **NOTE**

Once oil has been added, a visual check should show oil about 1-2 threads from running out of the fill hole. If using the dipstick to check oil level, DO NOT screw in the dipstick while checking.



# **NOTE**

Check oil often during the break-in period. Refer to the Maintenance section for recommended service intervals.


Add Engine Oil Cont'd.

# CAUTION

The engine is equipped with a low oil shut-off and will stop when the oil level in the crankcase falls below the threshold level.

### **NOTE**

We consider the first 5 hours of run time to be the break-in period for the engine. During the break-in period we recommend using standard automotive non-synthetic blended oils. After the break-in period synthetic lubricant can be used but is not required. Avoid bogging or lugging the engine down and avoid prolonged running at constant RPM. After the 5 hour break-in period, change the oil. Using synthetic lubricants does not increase the recommended oil change interval.




### **NOTE**

Weather will affect engine oil and engine performance. Change the type of engine oil used based on weather conditions to suit the engine needs.

### Add Engine Fuel

- Use clean, fresh, regular unleaded fuel with a minimum octane rating of 87 and an ethanol content of less than 10% by volume.
- 2. DO NOT mix oil with fuel.
- 3. Clean the area around the fuel cap.
- 4. Remove the fuel cap.
- 5. Slowly add fuel to the tank. DO NOT OVERFILL. Fuel can expand after filling. A minimum of ¼ in. (6.4 mm) of space left in the tank is required for fuel expansion, more than ¼ in. (6.4 mm) is recommended. Fuel can be forced out of the tank as a result of expansion if it is overfilled, and can affect the stable running condition of the product. When filling the tank, it is recommended to leave enough space for the fuel to expand.
- 6. Screw on the fuel cap and wipe away any spilled fuel.



## **!** CAUTION

Use regular unleaded gasoline with a minimum octane rating of 87.

Do not mix oil and gasoline.

Fill tank to approximately ¼ in. (6.4 mm) below the top of the tank to allow for fuel expansion. DO NOT pump gas directly into the engine at the gas station. Use an approved container to transfer the fuel to the engine.

DO NOT fill fuel tank indoors.

DO NOT fill fuel tank when the engine is running or hot. DO NOT overfill the fuel tank.

DO NOT light cigarettes or smoke when filling the fuel tank.

# A WARNING

Pouring fuel too fast through the fuel screen may result in blow back of fuel at the operator while filling.

#### Add Engine Fuel Cont'd.

# **NOTE**

Our engines work well with 10% or less ethanol blend fuels. When using blended fuels there are some issues worth noting:

- Ethanol-gasoline blends can absorb more water than gasoline alone.
- These blends can eventually separate, leaving water or a watery goo in the tank, fuel valve and carburetor.
- With gravity-fed fuel supplies, this compromised fuel can be drawn into the carburetor and cause damage to the engine and/or potential hazards.
- There are only a few suppliers of fuel stabilizer that are formulated to work with ethanol blend fuels.
- Any damages or hazards caused by using improper fuel, improperly stored fuel, and/ or improperly formulated stabilizers, are not covered by manufacture's warranty.

It is advisable to always shut off the fuel supply, run the engine to fuel starvation and drain the tank when the equipment is not in use for more than 30 days.

### **Chipper-Shredder Location**


Never operate the chipper-shredder indoors or inside any confined spaces, enclosures or buildings; including garages, basements, and sheds. The chipper-shredder must have at least 5 ft. (1.5 m) of clearance on all sides from combustible materials at all times. The chipper-shredder must also have 3 ft. (91.4 cm) or more of clearance on all sides of the at all times to allow for adequate cooling, maintenance and servicing. Chipper-shredders should never be started or operated in the bed of a truck (regular, flat or otherwise), under staircases/stairwells, next to walls or buildings, or in any other location that will not allow for adequate cooling of the unit and/or the muffler, or adequate safety to the operator, assistants, or bystanders. Place the chipper-shredder in a well-ventilated area. DO NOT place the chipper-shredder near vents or intakes where exhaust fumes could be drawn into occupied or confined spaces. Carefully consider wind and air currents when positioning the unit. Allow the unit to properly cool before transport or storage. The chipper-shredder needs to be on a dry level surface with good footing. (Even while not in operation) DO NOT work on mud, ice, tall grass, brush or snow. DO NOT work on asphalt, brick, rock, concrete or other harden surfaces. DO NOT position the unit next to or facing any buildings, walls or fences, that could cause any projectiles to ricochet back at the operator or bystanders.


# A WARNING

During operation the muffler and exhaust fumes produced will become hot. If adequate cooling and breathing space are not supplied, or if the chippershredder is blocked or contained, temperatures can become extremely heated and may lead to fire.

### Work Area

Always operate the chipper-shredder outdoors in a large, open area on solid ground that will allow for good footing and ventilation. Keep a clean and clear immediate area around the chipper-shredder at all times. Ensure no pets, children or bystanders are in the immediate or surrounding areas at any time. Debris and projectiles can be launched up to 75 ft. (22.9 m) in diameter in all directions surrounding the chipper-shredder. Assistants must also be out of the immediate and surrounding areas while chipping or shredding is being performed. The operator must be in the "Safe Zone" at all times when the spark plug wire is connected and/or the engine is on.





### \land DANGER

Never stand directly in front of the chipper chute or deflector chute. Do not lean over or reach across the shredder chute. Debris and projectiles may be discharged through these areas and may cause damage or injury.

### Before Each Use Inspect the Chipper-Shredder


- 1. Make sure the spark plug wire has been disconnected and engine has been grounded.
- 2. Visually inspect all attachments and chutes for loose fittings, cracks, fraying or other damage.
- 3. DO NOT operate the chipper-shredder if there is any indication of damage to parts or the unit.
- 4. DO NOT operate the chipper-shredder if there are any clogged chutes. Remove all debris before operation.
- 5. Inspect the engine and make sure the oil level and fuel level are correct before operating.
- 6. Clean and inspect the spark arrestor regularly (follow spark arrestor maintenance schedule).
- 7. Inspect the collection bag for any fraying, holes or damage. Never use a damaged collection bag.
- 8. Inspect the work area for any distractions or elements that may prevent operator safety or proper operation.

### \land DANGER

DO NOT operate a damaged chipper-shredder, or one with damaged or loose parts. Operating a damaged unit or one with loose parts may cause damage to the product or injury to the user. Make sure all parts are in good condition and secure before operation.


### **Starting the Engine**

- 1. Make certain the chipper-shredder is on a flat, level surface.
- 2. Re-attach the spark plug wire to the spark plug. Make sure the connection is secure.
- 3. Turn engine switch to "ON" position. (A)




#### Starting the Engine Cont'd.


4. Turn the fuel valve to the "ON" position. (B)




5. Move the choke lever to the "Choke" position. (C)



6. Pull the starter cord slowly until resistance is felt and then pull rapidly. **SEE NOTE BELOW.** 



7. As engine warms up, move the choke lever to "Run."(D)



# **OPERATION**

# **NOTE**

Keep choke lever in "Choke" position for only 1 pull of the recoil starter. After first pull, move choke lever to the "Run" position for up to the next 3 pulls of the recoil starter. Too much choke leads to spark plug fouling/engine flooding due to the lack of incoming air. This will cause the engine not to start.

# **NOTE**

If the engine starts but does not run make certain that the chipper-shredder is on a flat, level surface. The engine is equipped with a low oil sensor that will prevent the engine from running when the oil level falls below a critical threshold.

# **NOTE**


Pulling the recoil cord will spin the impeller and this will make noises. These noises are normal and should be made as the cord is pulled and the impeller spins.

### **Chipper-Shredder Operation**

# \land DANGER

This machine has rotating blades and parts capable of amputating body parts. This machine can also throw objects at high velocity, long distances. Exercise extreme caution when operating the chipper-shredder. NEVER insert body parts or foreign object into any chute at any time. Never look directly into any chute, as projectiles can backfire.

1. ALWAYS wear ear and eye protection, protective shoes and clothing, and proper safety gear.



- Block tires and put both support mounts in the DOWN position to prevent unintended movement of the chipper-shredder during operation.
- 3. Tie back long hair. Do not wear loose fitting clothing or jewelry.
- 4. Make sure surrounding, immediate and safe zones are clear of distractions and debris.
- 5. Do not attempt to chip or shred material that is larger than specified. This may damage the unit or cause injury.
- 6. Make sure the materials that are going to be chipped or shredded are free of any rocks, trash, metals and other foreign objects.
- 7. Make sure wood to be chipped has been "trimmed" down and do not have any excessive branches.
- 8. Make sure wood to be chipped or leaves/brush to be shredded are not "wet" as this may clog the chutes.
- 9. Keep all chutes, deflectors and guards assembled and in place at all times.

Chipper-Shredder Operation Cont'd.

# \land DANGER

If the impeller or blades strike a foreign object, stop engine immediately. Do not continue use until chutes and unit have been thoroughly inspected. Do not attempt to unclog any jam or chute while engine is on or spark plug wire is connected.

# A WARNING

ALWAYS use the chipper-shredder for its intended uses only. The chipper-shredder should only be used to chip branches 3 in. (7.6 cm) or less in diameter, or to shred leaves and brush. DO NOT chip anything that is larger than 3 in. (7.6 cm) in diameter.

NEVER modify, alter or change the chippershredder in anyway. Modifications will void the warranty and may result in damage or injury. DO NOT modify or change the engine and operating speeds. These changes can cause safety issues. ONLY operate the chipper-shredder in daylight. NEVER operate, or let anyone else operate, the chipper-shredder while under the influence of alcohol, drugs, or medication.

NEVER leave the chipper-shredder unattended while the engine is running.

Avoid contact with the muffler, as it can cause serious burns.

# **NOTE**

Always be aware of who and what is in the immediate and surrounding areas of the chippershredder. Operators should always work in the SAFE ZONE only.

### **Chipping and Shredding Tips**

#### Chipping

- 1. Make sure wood is less than 3 in. (7.6 cm) in diameter.
- 2. Make sure wood is dry.
- 3. Make sure all smaller branches have been pruned for the wood.
- 4. Make sure pieces are long enough to be fed through the chute.
- 5. Large pieces can be rotated and alternately inserted and retracted as they are fed.
- 6. Always maintain control with two hands of what is being fed, to prevent "whipping" around.
- 7. Standing in the safe zone will prevent any damage or injury if a piece is kicked back out of the chute.

# **WARNING**

Never insert pieces larger than 3 in. (7.6 cm) in diameter as this may cause damage or injury.

Small pieces may be fed carefully using a larger piece. Never insert smaller pieces using your hands.

If larger pieces will not chip, get pushed backed by the chipper, or can not be controlled, remove at once.

Never feed more than one branch or piece of wood into the chute at a time.

#### Shredding

- 1. Inserting smaller loads at a time will prevent overloading of the chute.
- 2. Make sure material is dry.
- 3. Make sure material is free of trash, metal, rocks, and foreign objects.
- 4. Air flow will draw loads into the chute, pushing or shoving the loads is not necessary.
- 5. Branches larger than 1/2 in. (1.3 cm) in diameter are not recommended, as they can damage the blades.
- 6. Vines are not recommended as they can clog or damage the blades.

# **MARNING**

Never insert any item into the chute to "assist" in the feeding of any load.

Never insert completely wet material into the chute. If material is "damp" then alternate with dry loads to prevent clogging. Chipping and Shredding Tips Cont'd.

# **NOTE**

After all material has been processed it is recommended that the unit run for short period to clear out any left over material that may still be in the chutes or flail housing.

### **Clearing the Shredding Chute**

If the shredding chute gets slightly clogged, then firmly grasp the handle and gently rock the unit back and forth to try and dislodge or shift the material that may be causing the clog. This may help to loosen and draw the material better into the flail housing and impeller. If slightly rocking the unit fails then:

- 1. Stop the engine.
- 2. Turn the fuel valve to the "OFF" position.
- 3. Disconnect the spark plug wire.
- 4. Using your hands, remove the material that is still atop the shredding chute. DO NOT stick your hands in the chute, only remove the material on top.
- Using a branch, or other piece of wood less than 1/2 in. (1.3 cm) in diameter try and dislodge the material.
- Once cleared, remove the branch, reconnect the spark plug wire, turn the fuel valve "ON," and restart the engine.

# **NOTE**

If the clog appears to be serious, then shut the engine off, disconnect the spark plug wire, and allow the unit to cool before draining the fuel and opening the flail housing to remove the clogged material.

### **Emptying the Collection Bag**

- 1. Stop the engine.
- 2. Turn the fuel valve to the "OFF" position.
- 3. Disconnect the spark plug wire.
- 4. Using your hands, release the draw string on the collection bag.
- 5. Remove the collection bag from the deflector chute and empty bag.
- Once emptied, reconnect the collection bag by pulling the draw string tight, then reconnect the spark plug wire, turn the fuel valve "ON," and restart the engine.

### **NOTE**

Do not let the collection bag fill to capacity before emptying. It is recommended to empty the bag before it fills completely to minimize damage to the bag.

### **Stopping the Engine**

- 1. Turn the fuel valve to the "OFF" position.
- 2. Let the engine run until fuel starvation has stopped the engine. This usually takes a few minutes.
- 3. Turn the engine switch to the "OFF" position.
- 4. Disconnect spark plug wire.

**Important:** Always ensure that the Fuel Valve and the Engine Switch are in the "OFF" position when the engine is not in use.

# **NOTE**

If the engine will not be used for a period of two (2) weeks or longer, please see the Storage section for proper engine and fuel storage.

# **NOTE**

As the engine shuts off and the blades wind down, some noises in the flail housing can be made, these are normal, but any weird noises may be damage and if these occur the unit should be inspected.

### **Operation at High Altitude**

The density of air at high altitude is lower than at sea level. Engine power is reduced as the air mass and air-fuel ratio decrease. Engine power and output will be reduced approximately 31/2% for every 1000 feet of elevation above sea level. This is a natural trend and cannot be changed by adjusting the engine. At high altitudes increased exhaust emissions can also result due to the increased enrichment of the air fuel ratio. Other high altitude issues can include hard starting, increased fuel consumption and spark plug fouling. To alleviate high altitude issues other than the natural power loss, Champion Power Equipment can provide a high altitude carburetor main jet. The alternative main jet and installation instructions can be obtained by contacting Customer Support. Installation instructions are also available in the Technical Bulletin area of the Champion Power Equipment internet site.

The part number and recommended minimum altitude for the application of the high altitude carburetor main jet is listed in the table below.

In order to select the correct high altitude main jet it is necessary to identify the carburetor model. For this purpose, a code is stamped on the side of the carburetor. Select the correct main jet part number corresponding to the carburetor code found on your particular carburetor.

Carburetor Code	Part Number	Altitude
16100 7500511	16161-Z153510-00A0	3000 ft. (914.4 m)
16100-Z590511- 01M0	16161-Z153310-00A0	6000 ft. (1828.8 m)

### 🗥 WARNING

Operation using the alternative main jet at elevations lower than the recommended minimum altitude can damage the engine. For operation at lower elevations, the standard main jet must be used. Operating the engine with the wrong engine configuration at a given altitude may increase its emissions and decrease fuel efficiency and performance. The owner/operator is responsible for all periodic maintenance.

### A DANGER

Always disconnect the spark plug wire during times of inactivity, cleaning and maintenance. This will prevent any accidental start up that may cause damage or injury.

### **MWARNING**

Never operate a damaged or defective chipper-shredder.

### A WARNING

Improper or neglected maintenance will void your warranty.

### **NOTE**

For service or parts assistance, contact our help line at **1-877-338-0999**.

Complete all scheduled maintenance in a timely manner. Correct any issue before operating the log splitter.

#### **Engine Maintenance**

To prevent accidental starting, remove and ground spark plug wire before performing any service.


#### 0il

Change oil when the engine is warm. Refer to the oil specification to select the proper grade of oil for your operating environment.

- 1. Remove the oil drain plug with a 12 mm socket and extension. (Not included)
- 2. Allow the oil to drain completely.
- 3. Replace the drain plug.
- 4. Remove oil fill cap/dipstick to add oil.
- 5. Add up to 1.2 qt (1.1 L) of oil and replace oil fill cap/dipstick. DO NOT OVERFILL.
- 6. Dispose of used oil at an approved waste management facility.

# **MAINTENANCE AND STORAGE**

#### Oil Cont'd.



### **NOTE**


Once oil has been added, a visual check should show oil about 1-2 threads from running out of the fill hole. If using the dipstick to check oil level, DO NOT screw in the dipstick while checking.

## AWARNING

Used oil is a hazardous waste product and must be disposed of properly. Do not discard with household waste. Check with your local authorities, service center, or dealer for safe disposal/recycling facilities.

#### Spark Plugs

- 1. Remove the spark plug cable from the spark plug.
- 2. Use a spark plug socket (included) to remove the plug.
- 3. Inspect the electrode on the plug. It must be clean and not worn to produce the spark required for ignition.
- 4. Make certain the spark plug gap is 0.7 0.8 mm (0.028 0.031 in.).



- 5. Refer to the spark plug section on the Specifications page when replacing the plug.
- 6. Carefully thread the plug into the engine.
- 7. Use a spark plug socket (included) to firmly install the plug.
- 8. Attach the spark plug wire to the plug.

#### Air Filter

- 1. Unscrew wing nut to remove the air filter cover.
- 2. Remove the supporter and foam element.
- 3. Tap the foam element to remove dirt and debris. Use compressed air (25 PSI) to clear debris.
- 4. For the foam element: Wash in liquid detergent and water. Squeeze thoroughly dry in a clean cloth.
- 5. Saturate in clean engine oil.
- 6. Squeeze in a clean, absorbent cloth to remove all excess oil.
- 7. Reassemble the elements and the supporter.
- 8. Reattach the air filter cover and snap in place.
- 9. Tighten wing nuts.

### **Chipper-Shredder Maintenance**

Make certain that the chipper-shredder is kept clean and stored properly. Only operate the unit on a flat, level surface in a clean, dry operating environment. DO NOT expose the unit to extreme conditions, excessive dust, dirt, moisture or corrosive vapors.

Inspect all air vents and cooling slots to ensure that they are clean and unobstructed.

Inspect all chutes and housing and make sure they are free of dirt, dust, and debris.

Check and tighten all bolts and nuts. It is possible for connections to vibrate loose over time.

### Cleaning

### **!** CAUTION

DO NOT use a garden hose or water to clean the engine or chipper-shredder.


Water can contaminate the fuel system and can enter the engine through the cooling slots and damage the engine.

Clear the debris from the chutes and engine. Use a damp cloth to clean exterior surfaces of the engine and chippershredder.

Use a soft bristle brush to remove excess dirt and oil. Use an air compressor (25 PSI) to clear dirt and small debris. Wipe all metal parts with an oily rag to help prevent rust and corrosion.

#### Flail Housing and Impeller Cleaning

- 1. Make sure spark plug wire is disconnected.
- 2. Disconnect the recoil housing on the front of the engine.
- 3. Disconnect the deflector chute #36. (A)
- Disconnect the upper #44 and lower #50 hopper assemblies, the inlet guide #51 and the outer flail housing assembly #53, all together. (B)
- 5. Disconnect the shredder screen #33. (C)
- Use compressed air (25 PSI) or brush to clean the inner flail housing assembly #22, impeller assembly #28, flail blades #26, and shredder blades #29.
- Once all debris and dust has been blown out or removed, reconnect the shredder screen, outer flail housing, inlet guide, hopper assemblies, and the deflector chute, making sure all bolts and nuts are tightened. Do not over tighten.




## **AWARNING**

Do not use the chipper-shredder if any part is lost or damaged while cleaning. Get lost or damaged parts replaced before use. Do not use the chippershredder if any part is loose, not fitting correctly or not fully re-assembled.


#### **Blade Sharpening**

Sharpening of the shredder blade, flail blades and chipper blades are required maintenance to be performed by a professional service center or knowledgeable and experienced owners only. Sharpening of the blades will keep the chipper-shredder performing at a higher quality than with dull blades. Sharp blades will chip or shred material faster and easier, and cause the engine and other parts to work less. Blades are not covered under warranty as they are a wear item, and therefore should be sharpened regularly to keep their edge and to ensure a longer life of the blades, other parts and engine.

- 1. Make sure spark plug wire is disconnected.
- 2. Disconnect the recoil housing on the front of the engine.
- 3. To get to the blades and impeller, the outer flail housing assembly (#53) must be removed. The steps in the flail housing and impeller cleaning section should be followed to remove it and the shredder screen (#33). (A)




- Once the outer flail housing and shredder screen are removed, remove the 7/16 screw (#32), 7/16 lock washer (#31) and washer ø12 (#30) from the engine cam shaft. (B)
- 5. DO NOT remove the flat key (#15) when removing the screw, washers.




Blade Sharpening Cont'd.


- 6. Once the 7/16 screw, lock washer, and washer are removed, the impeller (#28) can be removed from the cam shaft of the engine.
- 7. Removing the impeller will make it easier to remove and sharpen the shredder blade, flail blades, and chipper blades.
- To remove the shredder blade (#29), unscrew both the M8x25 bolts (#54), washers ø8 (#13), lock washers ø8 (#24) and M8 lock nuts (#55). (C)



- 9. To remove the flail blades (#26), unscrew the M10 lock nut (#27) from the shoulder pin (#25). (D)
- 10. Repeat for all 4 flail blades.



- 11. To remove the chipper blade (#56), unscrew M8 lock nut (#55), lock washer ø8 (#24), washer ø8 (#13) from the M8x30 bolt (#66). Each chipper blade is secured with two M8x30 bolts, lock washer, washer and lock nut. (E)
- 12. Repeat for second chipper blade.



#### **Maintenance Schedule**

Follow the service intervals indicated in the schedule below. Service your chipper-shredder more frequently when operating in adverse conditions. Contact our help line at **1-877-338-0999** to locate the nearest Champion Power Equipment authorized service dealer for your chipper-shredder or engine maintenance needs.

Every time of use or daily		
Check engine oil level		
Clean around air intake and muffler		
Check air filter		
Check for loose or damaged parts		
Inspect all chutes and guards		
First 5 Hours		
Change engine oil (break in period)		
Every 25 Hours or per 1 month		
Change engine oil		
Clean air filter		
Inspect all blades, sharpen if needed		
Every 50 hours or per 6 months		
Clean and adjust spark plug		
Check cooling fan		
Every 100 hours or per 1 year		
Check/adjust valve clearance*		
Clean fuel tank and filter*		
Every 200 hours or per 2 years		
Check/replace fuel line		
Change spark plug		
Every 250 hours		
Clean combustion chamber		

\*To be performed by knowledgeable, experienced owners or Champion Power Equipment certified dealers.

#### Storage

Refer to the maintenance sections for proper cleaning instructions. Always disconnect the spark plug wire in times of inactivity, maintenance, and storage. This will help to prevent any unintended engine start ups.

# WARNING

Never store the chipper-shredder inside next to appliances where there is a source of heat or open flame, spark or pilot light because they can ignite gasoline vapours. DO NOT store a chipper-shredder near fertilizer or any corrosive material.

Even with an empty gas tank, gasoline vapours could ignite.

#### **Chipper-shredder Storage**

- 1. The chipper-shredder needs to be cool for at least 5 minutes before storing.
- 2. Clean the chipper-shredder before storage according to the Maintenance section.
- 3. Store the unit in a clean, dry place out of direct sunlight.

#### Engine Stored for Less than 30 Days

- 1. Add a properly formulated fuel stabilizer to the tank.
- 2. Run the engine for a few minutes so the treated fuel cycles through the fuel system and carburetor.
- 3. Turn the fuel valve to the "Off" position.
- 4. Let the engine run until fuel starvation has stopped the engine. This usually takes a few minutes.
- 5. The engine needs to cool completely before cleaning and storage.
- 6. Clean the engine according to the maintenance section.

#### **Engines Stored for Over 30 Days**

- 1. Add a properly formulated fuel stabilizer to the tank.
- 2. Run the engine for a few minutes so the treated fuel cycles through the fuel system and carburetor.
- 3. Turn the fuel valve to the "Off" position.
- 4. Let the engine run until fuel starvation has stopped the engine. This usually takes a few minutes.
- 5. The engine needs to cool completely before cleaning and storage.
- 6. Clean the engine according to the maintenance section.
- 7. Change the oil.
- Remove the spark plug and pour about 1/2 ounce (14.8 mL) of oil into the cylinder. Crank the engine slowly to distribute the oil and lubricate the cylinder.

# **SPECIFICATIONS**

### **Chipper-Shredder Specifications**

- Max Diameter Chipper Material . . . . . . 3 in. (7.6 cm)
- Max Diameter Shredder Material ... 0.5 in. (1.3 cm)
- Overall Dimensions

### **Engine Specifications**

_	Model R338P
-	Displacement
_	Type
-	Start Type Recoil

### Fuel

Fuel capacity is 1.8 gallons (6.9 L). Use regular unleaded gasoline with a minimum octane rating of 87 and an ethanol content of less than 10% by volume.


### 0il

Use 10W-30 automotive oil.

Oil capacity is 37.2 fl. oz (1100 ml).

#### DO NOT OVERFILL.

Please reference the following chart for recommended oil types for use in the chipper-shredder.



## **NOTE**

Weather will affect engine oil and engine performance. Change the type of engine oil used based on weather conditions to suit the engine needs.

### **Spark Plugs**

OEM spark plug: NHSP F6RTC

**Replacement spark plug:** NGK BPR6ES or equivalent Make certain the spark plug gap is 0.7 - 0.8 mm or (0.028 - 0.031 in.).

### Maintenance Valve Clearance

- Intake: 0.10 - 0.15 mm (0.0039 - 0.0059 in.)

Exhaust: 0.15 - 0.20 mm (0.0059 - 0.0079 in.)
Note: Tech bulletin regarding the valve adjustment
procedure is on www.championpowerequipment.com.

### An Important Message About Temperature

Your Champion Power Equipment product is designed and rated for continuous operation at ambient temperatures up to 40°C (104°F). When your product is needed your product may be operated at temperatures ranging from -15°C (5°F) to 50°C (122°F) for short periods. If the product is exposed to temperatures outside this range during storage, it should be brought back within this range before operation. In any event, the product must always be operated outdoors, in a well-ventilated area and away from doors, windows and other vents.

## TROUBLESHOOTING

Problem	Cause	Solution
Engine will not start	No fuel	Add fuel
	Faulty spark plug	Replace spark plug
	Unit loaded during startup	Remove load from unit
Engine starts but runs roughly	Low oil level	Fill crankcase to the proper level
		Place chipper-shredder on a flat, level surface
	Choke in the wrong position	Adjust choke
	Spark plug wire loose	Attach wire to spark plug
Engine shuts down during operation	Out of fuel	Fill fuel tank
	Low oil level	Fill crankcase to the proper level
		Place chipper-shredder on a flat, level surface
Engine cannot supply enough power or overheating	Insufficient ventilation	Check for air restriction. Move to a well ventilated area
No materials are discharged	Flail housing clogged	Stop engine immediately, disconnect spark plug, take apart flail housing to clear clog
	Deflector chute clogged	Stop engine immediately, disconnect spark plug, take apart deflector chute to clear clog
	Collection bag is full	Stop engine, disconnect spark plug, empty collection bag
Discharge rate slows or discharge material changes	Chipper blades, shredder blade and flail blades are dull	Stop engine, disconnect spark plug, take apart flail housing and check all blades. Sharpen if needed
Excessive vibration or unusual noise while engine is running or material is being processed	Foreign object(s) in chutes or flail housing	Stop engine immediately, disconnect spark plug, inspect all chutes and take apart flail housing to inspect for foreign object (s)
	Impeller overloaded with material	Allow impeller to run current material load through before adding more
	Material is too dry or thick for blades	Remove material immediately

#### For further technical support:

**Technical Service** Mon – Fri 8:30 AM – 5:00 PM (PST/PDT) Toll Free: 1-877-338-0999 tech@championpowerequipment.com

### WARRANTY\*

CHAMPION POWER EQUIPMENT 2 YEAR LIMITED WARRANTY

### **Warranty Qualifications**

To register your product for warranty and FREE lifetime call center technical support please visit:

#### https://www.championpowerequipment.com/register

To complete registration you will need to include a copy of the purchase receipt as proof of original purchase. Proof of purchase is required for warranty service. Please register within ten (10) days from date of purchase.

### **Repair/Replacement Warranty**

CPE warrants to the original purchaser that the mechanical and electrical components will be free of defects in material and workmanship for a period of two years (parts and labor) from the original date of purchase and 90 days (parts and labor) for commercial and industrial use. Transportation charges on product submitted for repair or replacement under this warranty are the sole responsibility of the purchaser. This warranty only applies to the original purchaser and is not transferable.

### Do Not Return The Unit To The Place Of Purchase

Contact CPE's Technical Service and CPE will troubleshoot any issue via phone or e-mail. If the problem is not corrected by this method, CPE will, at its option, authorize evaluation, repair or replacement of the defective part or component at a CPE Service Center. CPE will provide you with a case number for warranty service. Please keep it for future reference. Repairs or replacements without prior authorization, or at an unauthorized repair facility, will not be covered by this warranty.

### **Warranty Exclusions**

This warranty does not cover the following repairs and equipment:

#### Normal Wear

Products with mechanical and electrical components need periodic parts and service to perform well. This warranty does not cover repair when normal use has exhausted the life of a part or the equipment as a whole.

#### Installation, Use and Maintenance

This warranty will not apply to parts and/or labor if the product is deemed to have been misused, neglected, involved in an accident, abused, loaded beyond the product's limits, modified, installed improperly or connected incorrectly to any electrical component. Normal maintenance is not covered by this warranty and is not required to be performed at a facility or by a person authorized by CPE.

### **Other Exclusions**

This warranty excludes:

- Cosmetic defects such as paint, decals, etc.
- Wear items such as filter elements, o-rings, etc.
- Failures due to acts of God and other force majeure events beyond the manufacturer's control.
- Problems caused by parts that are not original Champion Power Equipment parts.

When applicable, this warranty does not apply to products used for prime power in place of a utility.

### Limits of Implied Warranty and Consequential Damage

Champion Power Equipment disclaims any obligation to cover any loss of time, use of this product, freight, or any incidental or consequential claim by anyone from using this product. THIS WARRANTY AND THE ATTACHED U.S. EPA and/or CARB EMISSION CONTROL SYSTEM WARRANTIES (WHEN APPLICABLE) ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

A unit provided as an exchange will be subject to the warranty of the original unit. The length of the warranty governing the exchanged unit will remain calculated by reference to the purchase date of the original unit.

This warranty gives you certain legal rights which may change from state to state or province to province. Your state or province may also have other rights you may be entitled to that are not listed within this warranty.

### **Contact Information**

#### Address

Champion Power Equipment, Inc. 12039 Smith Ave. Santa Fe Springs, CA 90670 USA www.championpowerequipment.com

#### **Customer Service**

Toll Free: 1-877-338-0999 info@championpowerequipment.com Fax no.: 1-562-236-9429

#### **Technical Service**

### CHAMPION POWER EQUIPMENT, INC. (CPE) AND THE UNITED STATES ENVIRONMENTAL PROTECTION AGENCY (U.S. EPA) EMISSION CONTROL SYSTEM WARRANTY

Your Champion Power Equipment (CPE) engine complies with U.S. EPA emissions regulations.

#### YOUR WARRANTY RIGHTS AND OBLIGATIONS:

The U.S. EPA and CPE are pleased to explain the Federal Emission Control System's Warranty on your 2020 small off-road engine and engine powered equipment. In the United States new equipment that use small off-road engines shall be designed, built and equipped to meet U.S. EPA regulations. CPE shall warrant the emission control system on your small off-road engine and equipment for the period of listed below, provided there has been no abuse, neglect, unapproved modification or improper maintenance of your equipment.

Your emission control system may include parts such as: carburetor, fuel tanks, fuel lines (for liquid fuel and fuel vapors), fuel caps, valves, canisters, filters, clamps, connectors, and other associated components. Where a warrantable condition exits, CPE will repair your small off-road engine at no cost to you including diagnosis, parts and labor.

#### **MANUFACTURER'S WARRANTY COVERAGE:**

This emission control system is warranted for two years. If any emission related part on your engine or equipment is defective, the part will be repaired or replaced by CPE.

#### **OWNER'S WARRANTY RESPONSIBILITIES:**

As the small off-road engine owner, you are responsible for the performance of the required maintenance listed in your Owner's Manual. CPE recommends that you retain all your receipts covering maintenance on your small off-road engine, but CPE cannot deny warranty solely for the lack of receipts.

As the small off-road engine owner, you should be aware that CPE may deny you warranty coverage if your small off-road engine or a part has failed due to abuse, neglect, or improper maintenance or unapproved modifications.

You are responsible for presenting your small off-road engine to an Authorized CPE distribution center or service center or alternate service outlet as soon as a problem exists. The warranty repairs shall be completed in a reasonable amount of time, not to exceed 30 days.

If you have any questions regarding your warranty coverage, you should contact:

Champion Power Equipment, Inc. Customer Service 12039 Smith Ave. Santa Fe Springs, CA 90670 1-877-338-0999 tech@championpowerequipment.com

#### **EMISSION CONTROL SYSTEM WARRANTY**

1. APPLICABILITY: This section applies to Emissions Control Systems on small off-road engines or equipment that use small off-road engines subject to the emission standards in this Article. The warranty period begins on the date the new engine or equipment is delivered to an ultimate purchaser and shall continue for 24 consecutive months thereafter.

#### 2. GENERAL EMISSIONS WARRANTY COVERAGE

CPE warrants to the ultimate purchaser of the new engine or equipment and to each subsequent owner that the Emissions Control System when installed is:

2a. Designed, built and equipped to conform to U.S. EPA emissions standards for spark-ignited engines at or below 19 kilowatts;

2b. Free from defects in materials and workmanship that cause the failure of a warranted part to be identical in all material respects to the part as described in the engine manufacturer's application for certification for a period of two years.

#### 3. THE WARRANTY ON EXHAUST AND EVAPORATIVE EMISSION-RELATED PARTS WILL BE INTERPRETED AS FOLLOWS:

- 3a. Any warranted part that is not scheduled for replacement as required maintenance in the Operators Manual required by subsection (e) must be warranted for the warranty period defined in subsection (b)(2). If any such part fails during the period of warranty coverage, it must be repaired or replaced by CPE according to subsection (3)(3d) below. Any such part repaired or replaced under the warranty must be warranted for a time not less than the any remaining warranty period.
- 3b. Any warranted emissions-related part that is scheduled only for regular inspection in the Operators Manual shall be warranted for the warranty period defined in subsection (b)(2). A statement in such written instructions to the effect of "repair or replace as necessary" shall advise owners of the warranty coverage for emissions related parts. Replacement within the warranty period is covered by the warranty and will not reduce the period of warranty coverage. Any such emission-related part repaired replaced under warranty shall be warranted for a time not less than the remaining warranty period.
- 3c. Any warranted emissions-related part that is scheduled for replacement as required maintenance in the Operators Manual shall be warranted for the period of time prior to the first scheduled replacement point for that part. If the part fails prior to the first scheduled replacement, the part shall be repaired or replaced by CPE according to Subsection (3)(3d) below. Any such emissionsrelated part repaired or replaced under warranty shall be warranted for a time not less than the remainder of the period prior to the first scheduled replacement point for such emissions-related part.
- 3d. Repair or replacement of any warranted emissions-related part under the Warranty provisions of this article shall be performed at no charge to the owner at a CPE Authorized Service Outlet.
- 3e. The owner of the small off-road engine shall not be charged for diagnostic labor that leads to the determination that a warranted part is in fact defective, provided that such diagnostic work is performed at a CPE Authorized Service Outlet.
- 3f. CPE shall pay for covered emissions warranty repairs at non-authorized service outlets under the following circumstances:
  - i. The service is required in a population center with a population over 100,000 according to U.S. Census 2000 without a CPE Authorized Service Outlet AND
  - ii. The service is required more than 100 miles from a CPE Authorized Service Outlet. The 100-mile limitation does not apply in the following states: Alaska, Arizona, Colorado, Hawaii, Idaho, Montana, Nebraska, Nevada, New Mexico, Oregon, Texas, Utah and Wyoming.
- 3g. CPE shall be liable for damages to other original engine components or approved modifications proximately caused by a failure under warranty of an emission-related part covered by the ECS Warranty.
- 3h. Throughout the Emissions Control Systems Warranty period, CPE shall maintain a supply of warranted emission-related parts sufficient to meet the expected demand for such emission-related parts.
- 3i. Any CPE Authorized, and approved emission-related replacement part may be used in the performance of any ECS Warranty maintenance or repair and will be provided without charge to the owner. Such use shall not reduce CPE's warranty obligation.
- 3j. Unapproved add-on or modified parts may not be used to modify or repair a CPE engine. Such use voids this Warranty and shall be grounds for disallowing a warranty claim. CPE shall not be liable hereunder for failures of any warranted parts of a CPE engine caused by the use of such an unapproved add-on or modified part.

# EMISSION-RELATED PARTS INCLUDE THE FOLLOWING: (using those portions of the list applicable to the engine)

Systems covered by this warranty	Parts Description
Fuel Metering System	Fuel regulator, Carburetor and internal parts
Air Induction System	Air cleaner, Intake manifold
Ignition System	Spark plug and parts, Magneto ignition system
Exhaust System	Exhaust manifold, catalytic converter
Miscellaneous Parts	Tubing, Fittings, Seals, Gaskets, and Clamps associated with these listed systems.
Evaporative Emissions	Fuel Tank, Fuel Cap, Fuel Lines (for liquid fuel and fuel vapors), Fuel Line Fittings, Clamps, Pressure Relief Valves, Control Valves, Control Solenoids, Electronic Controls, Vacuum Control Diaphragms, Control Cables, Control Linkages, Purge Valves, Gaskets, Liquid/Vapor Separator, Carbon Canister, Canister Mounting Brackets, Carburetor Purge Port Connector

#### **TO OBTAIN WARRANTY SERVICE:**

You must take your CPE engine or the product on which it is installed, along with your warranty registration card or other proof of original purchase date, at your expense, to any Champion Power Equipment dealer who is authorized by Champion Power Equipment, Inc. to sell and service that CPE product during normal business hours. Alternate service locations defined in Section (3)(f.) above must be approved by CPE prior to service. Claims for repair or adjustment found to be caused solely by defects in material or workmanship will not be denied because the engine was not properly maintained and used.

If you have any questions regarding your warranty rights and responsibilities, or to obtain warranty service, please write or call Customer Service at Champion Power Equipment, Inc.

Champion Power Equipment, Inc. 12039 Smith Ave. Santa Fe Springs, CA 90670 1-877-338-0999 Attn.: Customer Service tech@championpowerequipment.com