




Champion Power Equipment, Inc., Santa Fe Springs, CA USA

MODEL #100443



PARTS INFORMATION

BACKPACK BLOWER

SERIAL NUMBER RANGE: ALL



To order replacement parts please visit:
shop.championpowerequipment.com
or call **1-877-338-0999**.

TABLE OF CONTENTS

Parts Diagram (A) 3

Parts List (A)..... 4

Parts Diagram (B) 5

Parts List (B)..... 6

Parts Diagram (C) 7

Parts List (C)..... 8


Parts Diagram (D) 9

Parts List (D)..... 10

Parts Diagram (E) 11

Parts List (E)..... 12

PARTS DIAGRAM (A)



PARTS LIST (A)

#	Part Number	Description	Qty.
1	QS15Q63BF.2	Left Band Assembly	1
2	EB-520-E.5	Right Band Assembly	1
3	EB-650-10	Clip, Band	2
4	3WF-14-13	Clip, Mat	4
5	6MF-18-44A.5	Mat	1
	S/N: <181200552		
	QS15Q63BF.6		
	S/N: 181200552+		
6	GB6177 M5	Flange Nut M5, Black	7
7	EB-650.1-2	Frame	1
8	GB9074.4 M5 x 25	Bolt Assembly M5 x 25, Black	4
9	EB-650.1-4	Right Loop	1
10	GB818+GB96 M5 x 20	Bolt Assembly M5 x 20	4
11	EB-650.1-1	Left Loop	1
12	GB6177.1 M5	Flange Nut M5, Black	2
13	GB96 Ø5	Washer Ø5, Black	5
14	GB818 M5 x 16	Bolt M5 x 16, Black	4
15	EB-650-CE.1	Fuel Cap Assembly	1
	S/N: <181200552		
	QS15Q63BF.7.1		
	S/N: 181200552+		
16	EB-650-E.3	Fuel Tank Assembly	1
	S/N: <181200552		
	QS15Q63BF.7-1		
	S/N: 181200552+		
17	3WF-2.6B-2	Clip, Protective Grid	4
18	EB-650-11	First Protective Grid	1
	S/N: <181200552		
	QS15Q63BF-2		
	S/N: 181200552+		

#	Part Number	Description	Qty.
19	GB845 ST4.2 x 13	Screw ST4.2 x 13, Black	1
20	GB845 ST4.8 x 25	Screw ST4.8 x 25, Black	2
21	EB-650-12	Second Protective Grid	1
22	GB70.1-GB93-GB97 M5 x 35	Bolt Assembly M5 x 35, Black	4
23	GB9074.4 M5 x 14	Screw M5 x 14	2
24	EB-650.8	Rubber Pillar	1
25	EB-650.9	Safety Belt	1
26	GB70.1-GB93-GB97 M6 x 35	Bolt Assembly M6 x 35, Black	6
27	EB-650-2	Bracket	1
28	3WF-20.9-1	Screw M5 x 10, Black	1
29	3WF-20.9-2	Screw M5 x 16, Black	6
30	EB-650.6	Support	2
31	JB8870 Ø78 - Ø101	Clamp Ø78 - Ø101	1
32	EB-650.7-2	Hose	1
33	JB8870 Ø59 - Ø82	Clamp Ø59 - Ø82	1
34	EB-650.7.1	Swivel Joint	1
35	EB-650.7-3	Pipe, Straight	1
36	EB-650-E.5-1	End Pipe	1
37	GB62 M6	Wing Nut, Black	1
38	EB-650.7.2-A-1	Holder, Manipulator	1
39	GB5783 M6 x 45	Screw Bolt M6 x 45, Black	1
40	QS15Q63BF.3	Manipulator Assembly	1
	S/N: <181200552		
	QS15Q63BF.3(A)		
	S/N: 181200552+		
41	QS15Q63BF.1	Fan Assembly	1
	S/N: <181200552		
	QS15Q63BF.1(A)		
	S/N: 181200552+		
42	1E48FP-E-CHAMPION	Engine, 63 cc	1

PARTS DIAGRAM (B)





FIGURE B

PARTS LIST (B)

#	Part Number	Description	Qty.
1	EB-650-1	Intake Pipe	1
2	JB8870 Ø46 - Ø70	Clamp Ø46 - Ø70	1
3	GB70-GB93-GB97 M5 x 50	Bolt Assembly M5 x 50	2
4	1E48FP-8	Baffle	1
5	1E48FP.3-2	Choke Valve	1
6	1E48FP.3-1	Cover	1
7	1E48FP.3-3	Choke Level	1
8	GB845 ST2.9 x 8.5	Screw ST2.9 x 8.5	1
9	1E48FP-7	Sealing Gasket, Carburator	1
10	1E48FP-E.4	Carburator Assembly	1
11	1E48FP-6	Sealing Gasket, Pipe	1
12	GB70-GB93-GB97 M5 x 30	Bolt Assembly M5 x 30	2
13	1E48FP-5	Pipe	1
14	1E48FP-4	Gasket, Guide Air Plate	1
15	1E48FP-3	Gasket, Cylinder	1
16	1E48FP-9	Guide Air Plate	1
17	GB70-GB93-GB97 M5 x 10	Bolt Assembly M5 x 10	2
18	1E48FP-E-GJ-1	Muffler Gasket	1
19	1E48FP-E-GJ.1	Muffler	1
20	1E48FP-E-GJ.2	Heat Shield	1
21	GB70-GB97 M6 x 70	Bolt Assembly M6 x 70, Black	2
22	JB8870 Ø32 - Ø50	Clamp Ø32 - Ø50	1
23	EB-650.5.2	Cleaner Inside Cover	1
24	EB-650.5.1	Cleaner Plate	1
25	EB-650.5-4	Second Filter Element	1
26	EB-650.5-3	First Filter Element	1
27	EB-650.5-2	Cleaner Plate	1
28	EB-650.5-1	Cleaner Outside Cover	1
29	EB-650.5.3	Screw	2
30	1E40FP-3Z.4	Recoil Starter Assembly	1

#	Part Number	Description	Qty.
31	GB70-GB93-GB97 M5 x 20	Bolt Assembly M5 x 20, Black	4
32	QS15Q63BF-1	Engine Cover	1
33	GB70-GB93-GB97 M6 x 16	Bolt Assembly M6 x 16, Black	1


PARTS DIAGRAM (C)



PARTS LIST (C)

#	Part Number	Description	Qty.
1	GB845 ST4.8 x 25	Screw ST4.8 x 25,Black zinc-plating	3
2	EB-650.2.3	Second Half Volute Case	1
3	EB-650.2.1	Impeller	1
4	EB-650.7-1	Pan Joint	1
5	QS15Q63BF.1.1	First Half Volute Case	1
6	GB97 Ø5	Flat Washer Ø5, Black	9
7	GB818 M5 x 55	Bolt M5 x 55, Black	2
8	GB818 M5 x 16	Bolt M5 x 16, Black	7
9	EB-650.2-1	Plug	1


PARTS DIAGRAM (D)



PARTS LIST (D)

#	Part Number	Description	Qty.
1	EB-420-E.4.1-2	Lever	1
2	EB-420-E.4.1.1	Handle Case	1
3	EB-420-E.4.1-3	Rotating Block	1
4	GB97	Washer Ø5	1
5	GB/T845	Screw St4.8 x 16	1
6	EB-420-E.4.1-1	Block	1
7	EB-420-E.4.1.3	Trigger	1
8	EB-420-E.4.1.2	Handle Cover	1
9	GB/T845	Screw St2.9 x 19, Black	3
10	GB70.1	Screw M5 x 25, Black	1
11	QS15Q63BF.3.1(A)	Ignition Switch Assembly	1
12	EB-420-E.4.1-4	Spring	1
13	QS15Q63BF.3-1	Fuel Throttle	1
14	QS15Q63BF.3.1-1	Tube Sheath	1

PARTS DIAGRAM (E)



PARTS LIST (E)

#	Part Number	Description	Qty.
1	1E34F-2E-EMC.1-1	Cap, Spark Plug	1
2	1E40F-3A.8-2	Spring, Spark Plug Cap	1
3	BPMR7A	Spark Plug, BPMR7A	1
4	GB70-GB93-GB848 M5 x 20	Bolt Assembly M5 x 20	4
5	1E48FP-E-1	Cylinder	1
6	GB6171 M10 x 1	Nut M10 x 1	1
7	GB93 Ø10	Spring Washer Ø10	1
8	GB97 Ø10	Flat Washer Ø10	2
9	EB-500-E.1.4-FSH-ZZ	Rotor	1
10	1E40FP-3Z-11	Seal, OD25 x ID14.5 x 7	2
11	GB70-GB93-GB848 M5 x 35	Bolt Assembly M5 x 35, Black	4
12	1E48FP-E.2-1	Front Crankcase	1
13	GB119	Pin	2
14	GB276 OD35 x ID15 x 11	Bearing, OD35 x ID15 x 11	2
15	1E48FP.6-2	Gasket, Crankcase	1
16	EB-500-E.1.4-FSH-DZ	Ignition Coil	1
17	GB70-GB93-GB97 M4 x 20	Bolt Assembly M4 x 20	2
18	1E36F-2C.6.1B	Ignition Wire	1
19	1E46FP.1-3	Grommet	1
20	GB70-GB93-GB97 M5 x 20	Bolt Assembly M5 x 20, Black	1
21	1E46FP-2	Retainer	1
22	GB1099 3 x 13	Woodruff Key 3 x 13	1
23	1E48FP-E.1.1	Crankshaft	1
24	1E48FP-E.2-2	Back Crankcase	1
25	1E40FP-3Z-19	Ratchet	1
26	1E40FP-3Z-16	Nut M10	1
27	1E44F-2A.2-3	Needle Bearing, OD14 x ID10 x 15.5	1
28	1E40F-03.02.01	Ring, Piston Pin	2
29	1E48FP-E.1-1	Piston	1

#	Part Number	Description	Qty.
30	1E48FP.5-2	Piston Pin	1
31	1E48FP.5-4	The Second Piston Ring	1
32	1E48FP.5-3	The First Piston Ring	1
33	1E48FP-10	Gasket, Cylinder	1